



PARTS for 4422 Burners

part name	4422-2	4422-3	4422-4	4422-5	4422-6	4422-6-B	4422-7-A	4422-7-B	4422-8-A
Burner Only (assembly)	4422-2-BO	4422-3-BO	4422-4-BO	4422-5-BO	4422-6-BO	4422-6-BBO	4422-7-ABO	4422-7-BBO	4422-8-ABO
Body	3-2466-9	3-2466-9	3-2466-9	3-2466-9	3-2466-10	3-2466-10	3-3267-3	3-3267-3	3-3267-4
Gas Connection Assy.	4-8620-1	4-8620-1	4-8620-2	4-8620-3	4-8620-3	4-8620-3	4-8620-4	4-8620-4	4-8620-5
Gas Connection	3-2465-4	3-2465-4	3-2465-5	3-2465-6	3-2465-6	3-2465-6	3-3268-2	3-3268-2	4-6126-1
Gas Tube	3-2468-2	3-2468-2	3-2468-2	3-2468-2	3-2468-2	3-2468-2	†	†	†
Gas Tube Ext.	—	—	—	—	—	—	—	—	4-6121-1
Backplate	4-2459-2	4-2459-2	4-2459-2	4-2459-2	4-2459-2	4-2459-2	3-3269-2	3-3269-2	3-3269-2
Backplate Gasket	3-2607-1	3-2607-1	3-2607-1	3-2607-1	3-2607-1	3-2607-1	3-3272-1	3-3272-1	3-3272-1
Studs, Gas Conn. (4)	3-2584-1	3-2584-1	3-2584-1	3-2584-1	3-2584-1	3-2584-1	3-3325-1	3-3325-1	3-3325-1
Stud Hex Nuts (4)	R510-2219	R510-2219	R510-2219	R510-2219	R510-2219	R510-2219	R510-2259	R510-2259	R510-2259
Gas Conn. Gasket	3-2473-1	3-2473-1	3-2473-1	3-2473-1	3-2473-1	3-2473-1	3-3272-1	3-3272-1	3-3272-1
Air Tubes (8)	3-3643-1‡	3-3643-2‡	3-3640-2	3-3639-2	3-3554-2	3-5042-1	3-3273-3	3-3273-4	4-3684-2
Main Air Flange	3-2544-2	3-2544-1	4-1695-2	4-1695-3	4-1695-9	4-1695-9	4-1695-5	4-1695-5	8765-8x7-D
Main Air Flange Gasket	4-5371-2	4-5371-2	4-5371-2	4-5371-2	4-5371-2	4-5371-2	4-5371-3	4-5371-3	4-5371-3
Hex Head Cap Screws (4)	R066-2670			R066-2670			R066-2950		
Hex Nuts (4)	R510-2219			R510-2219			R510-2259		
Mounting (hard wall)	3-3257-1	3-3257-1	3-3257-1	3-3257-1	3-3257-1	3-3257-1	3-3270-1	3-3270-1	3-3270-1
Burner Tile (9")	4-2121-2	4-2121-2	4-2121-2	4-2121-2	4-2121-2	4-2121-2	4-2142-2	4-2142-2	4-2142-2
Cap Screws (8)	R066-2920			R066-2920			R066-3420		
Flat Washers (8)	R970-7300-C			R970-7300-C			R970-7370-C		
Mounting & Tile Assemblies									
<i>Standard</i>	<i>for Burner Complete w/9" Tile</i>								
Mounting & Tile Assy.*	3-6668-1	3-6668-1	3-6668-1	3-6668-1	3-6668-1	3-6668-1	3-6668-2	3-6668-2	3-6668-2
<i>LC Series</i>	<i>for Burner Complete w/9" Tile and Steel Jacket</i>								
Mounting & Tile Assy.*	3-6668-3	3-6668-3	3-6668-3	3-6668-3	3-6668-3	3-6668-3	3-6668-4	3-6668-4	3-6668-4
Tile & Jacket Assembly ^Δ	4-21583-1	4-21583-1	4-21583-1	4-21583-1	4-21583-1	4-21583-1	4-21583-2	4-21583-2	4-21583-2
Jacket	4-5377-3	4-5377-3	4-5377-3	4-5377-3	4-5377-3	4-5377-3	4-5378-3	4-5378-3	4-5378-3
<i>L4 Series</i>	<i>for Burner Complete w/9" Tile and 304 SST Jacket</i>								
Mounting & Tile Assy.*	3-6668-5	3-6668-5	3-6668-5	3-6668-5	3-6668-5	3-6668-5	3-6668-6	3-6668-6	3-6668-6
Tile & Jacket Assembly ^Δ	4-21583-3	4-21583-3	4-21583-3	4-21583-3	4-21583-3	4-21583-3	4-21583-4	4-21583-4	4-21583-4
Jacket	4-5377-4	4-5377-4	4-5377-4	4-5377-4	4-5377-4	4-5377-4	4-5378-4	4-5378-4	4-5378-4
<i>L9 Series</i>	<i>for Burner Complete w/9" Tile and 309 SST Jacket</i>								
Mounting & Tile Assy.*	3-6668-7	3-6668-7	3-6668-7	3-6668-7	3-6668-7	3-6668-7	3-6668-8	3-6668-8	3-6668-8
Tile & Jacket Assembly ^Δ	4-21583-5	4-21583-5	4-21583-5	4-21583-5	4-21583-5	4-21583-5	4-21583-6	4-21583-6	4-21583-6
Jacket	4-5377-6	4-5377-6	4-5377-6	4-5377-6	4-5377-6	4-5377-6	4-5378-5	4-5378-5	4-5378-5

* Includes complete mounting, tile, jacket, and retainer assembly.
† Gas tube is cast with Gas Connection for -7-A, -7-B, and -8-A sizes.

^Δ Includes tile and jacket only.
[‡] Includes 3-3638-1 adapter.

CONTACT

fna.sales@fivesgroup.com
T +1 800 626 3477 - F +1 216 373 4237

Fives North American Combustion, Inc.
4455 East 71st Street - Cleveland, OH 44105 - USA
www.fivesgroup.com

