



PARTS for 4422 "FM" Flangeless Mounting Burners

Part name	4422-2-FM	4422-3-FM	4422-4-FM	4422-5-FM	4422-6-FM	4422-6-BFM	4422-7-AFM	4422-7-BFM	4422-8-AFM
Burner only (assembly)	4422-2-BO	4422-3-BO	4422-4-BO	4422-5-BO	4422-6-BO	4422-6-BBO	4422-7-ABO	4422-7-BBO	4422-8-ABO
Body	3-2466-9	3-2466-9	3-2466-9	3-2466-9	3-2466-10	3-2466-10	3-3267-3	3-3267-3	3-3267-4
Double-Boss Burner only (assembly)**	4422D-2-BO	4422D-3-BO	4422D-4-BO	4422D-5-BO	4422D-6-BO	4422D-6-BBO	—	—	—
Double-Boss Body**	OC3-2042-1	OC3-2042-1	OC3-2042-1	OC3-2042-1	OC3-2042-2	OC3-2042-2	—	—	—
Gas Connection Assy.	4-8620-1	4-8620-1	4-8620-2	4-8620-3	4-8620-3	4-8620-3	4-8620-4	4-8620-4	4-8620-5
Gas Connection	3-2465-4	3-2465-4	3-2465-5	3-2465-6	3-2465-6	3-2465-6	3-3268-2	3-3268-2	4-6126-1
Gas Tube	3-2468-2	3-2468-2	3-2468-2	3-2468-2	3-2468-2	3-2468-2	†	†	†
Gas Tube Ext.	—	—	—	—	—	—	—	—	4-6121-1
Backplate	4-2459-2	4-2459-2	4-2459-2	4-2459-2	4-2459-2	4-2459-2	3-3269-2	3-3269-2	3-3269-2
Backplate Gasket	3-2607-1	3-2607-1	3-2607-1	3-2607-1	3-2607-1	3-2607-1	3-3272-1	3-3272-1	3-3272-1
Studs, Gas Conn (4)	3-2584-1	3-2584-1	3-2584-1	3-2584-1	3-2584-1	3-2584-1	3-3325-1	3-3325-1	3-3325-1
Stud Hex Nuts (4)	R510-2219	R510-2219	R510-2219	R510-2219	R510-2219	R510-2219	R510-2259	R510-2259	R510-2259
Gas Conn. Gasket	3-2473-1	3-2473-1	3-2473-1	3-2473-1	3-2473-1	3-2473-1	3-3272-1	3-3272-1	3-3272-1
Air Tubes (8)	3-3643-1‡	3-3643-2‡	3-3640-2	3-3639-2	3-3554-2	3-5042-1	3-3273-3	3-3273-4	4-3684-2
Main Air Flange	3-2544-2	3-2544-1	4-1695-2	4-1695-3	4-1695-9	4-1695-9	4-1695-5	4-1695-5	8765-8X7-D
Main Air Flange Gasket	4-5371-2	4-5371-2	4-5371-2	4-5371-2	4-5371-2	4-5371-2	4-5371-3	4-5371-3	4-5371-3
Hex Head Cap Screw (4)	← R066-2670 →				← R066-2950 →				→
Hex Nuts (4)	R510-2219	R510-2219	R510-2219	R510-2219	R510-2219	R510-2219	R510-2259	R510-2259	R510-2259
Flangeless Mounting (hard wall)	3-4928-1	3-4928-1	3-4928-1	3-4928-1	3-4928-1	3-4928-1	3-3459-1	3-3459-1	3-3459-1
Cap Screw (8)	← R066-2920 →				← R066-3420 →				→
Flat Washer (8)	← R970-7300-C →				← R970-7370-C →				→

Flangeless Mounting & Tile Assemblies

I. Standard	for Burner Complete w/9" Tile								
Mounting & Tile Assy.*	3-6668-30	3-6668-30	3-6668-30	3-6668-30	3-6668-30	3-6668-30	3-6668-31	3-6668-31	3-6668-31
Standard Burner Tile	4-2121-2	4-2121-2	4-2121-2	4-2121-2	4-2121-2	4-2121-2	4-2142-2	4-2142-2	4-2142-2
II. D Series	for Burner Complete w/ Double-Boss Body and 9" Tile								
Mounting & Tile Assy.*	3-6668-29	3-6668-29	3-6668-29	3-6668-29	3-6668-29	3-6668-29	—	—	—
Burner Tile (9") [Double-Boss]	4-2121-4	4-2121-4	4-2121-4	4-2121-4	4-2121-4	4-2121-4	—	—	—

* Includes complete mounting, tile, and retainer assembly.

** Double Pilot and Flame Supervisory connections.

† Gas tube is cast with Gas Connection for -7-A, -7-B, and -8-A sizes.

‡ Includes 3-3638-1adapter.

WARNING: Situations dangerous to personnel and property may exist with the operation and maintenance of any combustion equipment. The presence of fuels, oxidants, hot and cold combustion products, hot surfaces, electrical power in control and ignition circuits, etc., are inherent with any combustion application. Components in combustion systems may exceed 160°F (71°C) surface temperatures and present hot surface contact hazard. Fives North American Combustion, Inc. suggests the use of combustion systems that are in compliance with all Safety Codes, Standards, Regulations and Directives; and care in operation.

CONTACT

fna.sales@fivesgroup.com

T +1 800 626 3477 - F +1 216 373 4237

Fives North American Combustion, Inc.
4455 East 71st Street - Cleveland, OH 44105 - USA
www.fivesgroup.com



fives
Industry can do it