



Item no.	Part no.	Description
1-2	11-4917-1	Tile Retaining Hook (4 required) (normally not sold separately)
1-4	11-4977-1	Gasket for Gas Section
1-6	R066-4040	Burner Mounting Bolt, 3/4"-10 x 2" long (8 required) with plain washer and lock washer
2-4	11-3712-1	Ignition Transformer Bracket
2-8	4065-6N1-6A	Ignition Transformer for 60 Hz, or
	4065-5N1-6A	Ignition Transformer for 50 Hz
2-13	11-4911-4	Ignition Cable
4	11-5091-1	Gas Pilot Assembly (includes 11-5086-1 Gas Tube and 4-3587-1 Pilot Tip
	11-5086-2	Gas Tube (not visible--part of 11-5091-1 Gas Pilot Assembly)
	4020-LP-5/3	Nozzle Mix Pilot
4-1	1836-03	Needle Valve, 1/4"
4-3	4025-2-T	Pilot Tip Assembly (4-3587-1)
4-6	R240-2465	Spark Plug, 10mm
5-1	11-5003-2	Assembly of Oil Nozzle Adapter and Connection Plate (included in 11-5292-2 and 11-5292-1 Atomizer Assembly)
6	11-4896-5	Observation Port Assembly (includes parts 11-7747-1, 11-3702-1, 11-3701-1, and 11-3193-1
	11-7747-1	Observation Port Frame (part of 11-4896-5 Observation Port Assembly)
	11-3702-2	Window Glass (part of 11-4896-5 and 11-9814-1 Observation Port Ass'y)
	11-3701-1	Window Glass Gasket (part of 11-4896-5 and 11-9814-1 Observation Port Assembly)
	11-3193-2	Retaining Clip, 4 required (part of 11-4896-5 and 11-9814-1 Observation Port Assembly)
	(Alternate:)	
	11-9814-1	Observation Port and Mounting Assembly with UV Swivel and Sight Tube
	11-16040-1	Dual UV Mounting
6-7	R590-6542-S	Sight Tube
23-1	11-5026-2	Bracket for Air Motor
	11-9973-1	Bracket for Electric Control Motor