

CAST OUTER HOUSINGS

Part no.†	Blower designation
1-0337-1‡	2316-14/2, 2316-17/2, 2324-14/3
1-0374-1‡	2308-14/1, 2308-17/1
1-0401-2	2320-19/2, 2324-19/2, 2332-19/3
1-0418-2	2316-19/1
1-0454-1‡	2316-24/2
1-0455-1	2308-24/1
1-0471-1	2320-26/2, 2324-26/2
1-0472-1‡	2310-26/1, 2312-26/1, 2316-26/1
1-0488-1	2316-31/2
1-0489-1‡	2308-31/1
1-0498-1	2310-35/1, 2312-35/1
1-0658-1	2316-28/1
1-0702-2‡	2308-11/3, 2310-11/4, 2312-11/4
1-0735-1‡	2316-21/1, 2320-21/1, 2316-35/1, 2320-35/1, 2332-21/2 (included as part of 1-0773)
1-0827-1‡	2332-28/2, 2344-28/3
1-0997-1‡	2312-21/1
1-1666-2‡	2310-19/1, 2312-19/1
1-1775-1‡	2308-21/1, 2310-21/1 - Inlets

† The cast pattern number that may be found on the blower housing is determined by omitting the hyphen and the last number from the part number. Also, a zero appearing after the first hyphen may be omitted from the cast pattern number.

Example: Part Number 1-0374-1
Pattern Number 1-374

‡ Aluminum cast housings, others are cast iron.