



TABLE 3— Control Panel

Item	Description	LCH	
		20W, E; 25W, E; 30W, E; 40W, E;	20A, 25A 30A, 40A
1	Switch, Stop-Auto-Off	024-13272	024-13272
2	Knob, Stop-Auto-Off Switch	365-22494	365-22494
3	Gauge, Discharge Pressure	026-14294	026-14294
4	Gauge, Suction Pressure	026-14295	026-14295
5	Gauge, Oil Pressure	026-14296	026-14296
6*	Discharge Gauge Conn.	365-22554	365-22554
7*	Suction Gauge Conn.	365-22556	365-22556
8*	Oil Gauge Conn.	365-22564	365-22564
9	Gauge Stop Valve	022-02994	022-02994
10	Indicator Light	025-13551	025-13551
11*	Lock and Key	029-07382	029-07382
12*	Key Only	029-10876	029-10876
13	Operating Thermostat (1TH)	025-10056	025-10056
14	HP & LP Cut-out	025-15055001	025-15054001
15	Program Timer (1TR)	025-14531	025-14531
16	Relay 1R	024-11784	024-11784
17	Relay 2R	024-11784	024-11784
18	Relay 3R	024-11784	024-11784
19	Fuse Holder	025-13991	025-13991
20	Fuse (5 Amp)	025-15759	025-15759
21	Terminal Strip	225-14542	225-14542
22	Freeze Control (SC)	025-15053	025-15053
23	Harness, Wiring	365-22826	365-22826
24	Oil Pressure Cutout (OP)	025-14530	025-14530
	Compound, heat conductive (4 oz. can)	013-00898	013-00898
	(1 oz. tube)	013-01850	013-01850

*Not Shown

NOTE: For replacement starter contactors order from York by description, being sure to list original York Sales Order Number.