



TABLE 2 — UNIT COMPONENTS

ITEM NO.	DESCRIPTION	LCH130W	LCH130A	LCH150W	LCH150A
1	COOLER, INSULATED	366-91262	366-91641	366-91263	366-91462
2	COOLER, NON-INSULATED	366-91256	366-91639	366-91257	366-91640
3	TUBE (528 REQ'D)	007-06743 -004	007-06743 -004	007-06743 -004	007-06743 -004
4	HEAD, CONNECTION END	366-91264	366-91264	366-91264	366-91264
5	HEAD, BACK END	366-87596	366-87596	366-87596	366-87596
6	BAFFLE, PASS, CONNECTION END	366-87621	366-87621	366-87621	366-87621
7	BAFFLE, PASS, BACK END	066-87634	066-87634	066-87634	066-87634
8	GASKET, PASS BAFFLE AND HEAD	066-87637	066-87637	066-87637	066-87637
9	CONDENSER (INCLUDES ITEMS 10-14)	366-91629	—	366-90770	—
10	HEAD, FRONT	366-90688	—	366-90688	—
11	HEAD, REAR	366-30753	—	366-30753	—
12	TUBE NO. REQ'D.	007-07424 176	—	007-07424 200	—
13	GASKET, HEAD, FRONT	067-77469	—	067-77469	—
14	GASKET, HEAD, REAR	067-77468	—	067-77468	—
15	VALVE, RELIEF	022-01887	—	022-01887	—
16	VALVE, PURGE	022-01582	—	022-01582	—
17	VALVE, LIQUID STOP	022-03043	022-03043	022-03043	022-03043
18	DEHYDRATOR	026-20155	026-20155	026-20155	026-20155
19	CARTRIDGE (2 REQ'D. PER DEHYDRATOR)	026-15304	026-15304	026-15304	026-15304
20	VALVE, SOLENOID	025-20997	025-20997	025-20997	025-20997
21	VALVE, TX, LESS BODY	025-16570	025-16570	025-25977	025-25977
22	VALVE, TX, BODY	025-16571	025-16571	025-16571	025-16571
23	MOISTURE INDICATOR BODY CAP ASS'Y.	026-16957 026-16958	026-16957 026-16958	026-16957 026-16958	026-16957 026-16958