



TABLE 4— CONTROL PANEL

Item No.	Description	Part No.									
		LCX40 (W)(E)(A)	LC50 (W)(E)(A)	LCX50 (W)(E)(A)	LC60 (W)(E)(A)	LCX60 (W)(E)(A)	LC70 (W)(E)(A)	LCX75 (W)(E)(A)	LCX85 (W)(E)(A)	LC100 (W)(E)(A)	
1	Manual (On-Off-Stop) Switch	←	←	←	←	←	←	←	←	←	←
2	Suction Pressure Gauge	←	←	←	←	←	←	←	←	←	←
3	Discharge Pressure Gauge	←	←	←	←	←	←	←	←	←	←
4	Oil Pressure Gauge	←	←	←	←	←	←	←	←	←	←
5	Suction Gauge Conn.	←	←	←	←	←	←	←	←	←	←
6	Discharge Gauge Conn.	←	←	←	←	←	←	←	←	←	←
7	Oil Gauge Conn.	←	←	←	←	←	←	←	←	←	←
8	Indicator Light	←	←	←	←	←	←	←	←	←	←
9	Decorative Panel	←	←	←	←	←	←	←	←	←	←
10	Fuse Holder	←	←	←	←	←	←	←	←	←	←
11	Fuse	←	←	←	←	←	←	←	←	←	←
12	Knob (On-Off-Stop) Switch	←	←	←	←	←	←	←	←	←	←
13 *	Lock and Key	←	←	←	←	←	←	←	←	←	←
14 *	Key Only	←	←	←	←	←	←	←	←	←	←
15	1/4 Flare Union	←	←	←	←	←	←	←	←	←	←
16	Terminal Block	←	←	←	←	←	←	←	←	←	←
17	Oil Failure Switch (OPA & B)	←	←	←	←	←	←	←	←	←	←
18	HP & LP Pressure Cut-out	←	←	←	←	←	←	←	←	←	←
19	1-R Control Relay	←	←	←	←	←	←	←	←	←	←
20	2-R Control Relay	←	←	←	←	←	←	←	←	←	←
21	3-R Control Relay	←	←	←	←	←	←	←	←	←	←
22	SC Freeze Control	←	←	←	←	←	←	←	←	←	←
23	1-THS Capacity Control Thermo.	←	←	←	←	←	←	←	←	←	←
24	2-THS Low Temp. Thermo.	←	←	←	←	←	←	←	←	←	←
25	Angle Stop Valve (Gauges)	←	←	←	←	←	←	←	←	←	←
26	Wiring Harness	←	←	←	←	←	←	←	←	←	←
27	Marker Strip	←	←	←	←	←	←	←	←	←	←
28	Mounting Plate	←	←	←	←	←	←	←	←	←	←
29	Grommet	←	←	←	←	←	←	←	←	←	←
30	Mounting Stud	←	←	←	←	←	←	←	←	←	←
31	Gauge Header	←	←	←	←	←	←	←	←	←	←

* Not Shown

** On "A"-Models use Part No. 025-14742

NOTE: For replacement motors and starters, order from York, by description, being sure to list original York Sales Order Number.