



Item No.	Description	Part No.
1	Transformer	325-09025004
2	Relay, Time Delay (2TR)	024-12045001
3	Module, Motor Protector	025-19369002
4	Contactor (1M & 2M)	024-12405
5	Block, Terminal	025-12164
6	Relay, Time Delay (1TR)	024-16687
7	Control, Pressure (HP)	025-20054
8	Capacitor (1RC, 2RC, 3RC, 4RC)	024-20042
9	Control, Pressure, (1LP)	025-20768
10	Thermostat (1TH)	025-14237
11	Control, Oil Pressure	025-17151
12	Relay (3R)	024-12066
13	Relay (1R)	024-08695
14	Block, Terminal	025-14980
15	Fuseholder	025-05259
16	Fuse	025-04649
17	Relay (2R)	024-11772
18	Block, Terminal	025-14513
19	Fuseholder	325-06924011
20	Fuse	025-08445

FIG. 7 — MAIN CONTROL PANEL — LCHA20-17, -28, -63