



Item No.	Description	LCHA20	LCHA25	LCHA35	LCHA45
1	Cooler, Complete (Insulated)	366-58888	366-58889	366-58890	366-58891
2	Cooler (Less Heater, Wrapper & Insulation)	366-55605	366-55606	366-55607	366-55608
3	Tube	066-55360	066-55359	066-55359	066-55360
	No. Req'd.	108	134	216	215
4	Head, Front	366-55113	366-55114	366-55824	366-55808
5	Head, Rear	366-66425	366-66424	366-65545	366-65545
6	Gasket, Head & Pass Baffle (2 Req'd./Head)	066-56297	066-56298	066-55653	066-55553
7	Heater	025-17897	025-17897	025-17898	025-17898
8	Baffle, Pass (Front)	066-55343	066-55345	066-55347	066-55826
9	Baffle, Pass (Rear)	066-55344	066-55346	066-51902	066-55827
10*	Turbulator Spring	066-69902	066-69901	066-69901	066-69902

\* Not Shown

FIG. 21 — COOLER

ACCESSORY PARTS

Item No.	Description	Part No.
Gauge Kit		
1	Kit, Complete (Contains all items listed below)	466-46886T
2	Gauge, Discharge Pressure, 3-1/2" Dia.	026-14366
3	Gauge, Suction Pressure, 3-1/2" Dia.	026-14367
4	Gauge, Oil Pressure, 3-1/2" Dia.	026-18764
	Valve, Stop, 2-Way (Primore 2869)	022-04302