


Item No.	Description	Part No.
2	Fuse	025-05749
3	Capacitor, Run	024-20050
4	Contactior (8M, 14M)	024-18496
5	Contactior (2M, 4M)	024-18976
6	Contactior (5M, 6M, 11M, 12M)	024-18023
7	Contactior (1M, 3M)	024-18977
8	Block, Terminal	025-18807
9	Lug, Electrical	025-19282
10	Block, Terminal Base, Flat (8 Req'd.)	025-20944
11	Block, Terminal, End (2 Req'd.)	025-20946

FIG. 5 — POWER PANEL LCHA55-25C & 25D



Item No.	Description	Part No.	
		-46	-58
1	Fuseholder	025-13947	025-13947
2	Fuse	025-06079	025-11910
3	Capacitor, Run (2 Req'd.)	024-20050	024-20050
4	Contactior, (8M, 14M)	024-18496	024-18496
5	Contactior (5M, 6M, 11M, 12M)	024-18023	024-18023
6	Contactior (1M, 3M)	024-18977	024-18977
7	Lug, Electrical (2 Req'd.)	025-19282	025-19282
8	Block, Terminal (2 Req'd.)	025-18807	025-18807
9	Block, Term. Base, Flat (8 Req'd.)	025-20944	025-20944
10	Block, Terminal, End (2 Req'd.)	025-20946	025-20946

FIG. 6 — POWER PANEL LCHA55-46C, 46D, -58C & 58D