

**TABLE 1 - COMMON PARTS FOR ALL MODELS**

ITEM	DESCRIPTION	PART NUMBER	FIGURE
1	Logic / Trigger Board 60 Hz applications (includes 031-02505-001 board)	031-02757-002	2
	Logic / Trigger Board 50 Hz applications (includes 031-02505-002 board)	031-02757-003	2
2	Capacitor, Assembly	371-01086-000	5
3	Fuseholder for 7FU	025-34186-000	3
4	Fuseholder for 1FU-6FU ( 1 of 2 )	025-34185-000	3
5	Fuse, 4 Amp 7 FU	025-27973-000	3
6	Fastener, Panel Adj.	021-17252-000	1
7	Hose Barb, Plastic - Threads Into SCR Brick Assembly	023-20205-000	6
8	Hose, Clear Plastic order by the foot	028-12239-000	6
9	Coolant Header 3" PVC with Fill Plug	371-02561-513	6
10	Heat Exchanger	026-36596-000	6
Not Shown	Hose, connect heat exchanger to condenser water 150 PSI., 50 Ft Roll	028-11958-000	
Not Shown	Hose, connect heat exchanger to condenser water 300 PSI., 50 Ft Roll	028-11959-000	
11	Temperature Sensor kit ( thermistor, lugs, and plug )	031-02758-000	5
12	U16 Logic / Trigger Board EPROM (used on 031-02001-xxx board)	031-02029-001	2
12	U16 Logic / Trigger Board EPROM (used on 031-02505-xxx board)	031-02541-001	
13	U15 Battery Backed RAM for the Logic / Trigger Board	031-01620-000	2
14	Coolant Pump 50 / 60 Hz	026-32813-000	6
Not Shown	Inhibitor, Coolant	013-04129-000	

**TABLE 2 - COMMON PARTS PER MODEL**

ITEM	DESCRIPTION	PART NUMBER				FIGURE
		7L – 7LK	14L – 14LK	26L – 26LK	33L – 33LK	
15	Ground Terminal	025-34196-000	025-34197-000	025-34198-000	025-34198-000	2
Not Shown	Terminal Lug Kit ( 3 Lugs )	371-02576-101	371-02576-102	371-02576-103	371-02576-104	*
16	Bus Bar ( L1 )	371-02500-003	371-02500-003	371-01082-006	371-01082-006	4
17	Bus Bar ( L2 )	371-02500-002	371-02500-002	371-01082-005	371-01082-005	4
18	Bus Bar ( L3 )	371-02500-001	371-02500-001	371-01082-004	371-01082-004	4
19	Output Current Transformer	025-34195-001	025-34195-002	025-34195-003	025-37195-004	4, 5