

VARIABLE COMPONENTS

ITEM NO.	DESCRIPTION	ELECTRIC P. R. V. MOTOR								AIR P. R. V. MOTOR							
		LINE NO. 1	Q	LINE NO. 2	Q	LINE NO. 3	Q	LINE NO. 4	Q	LINE NO. 5	Q	LINE NO. 6	Q	LINE NO. 7	Q	LINE NO. 8	Q
		364-20625 MTC-67 L.V.	U A N	364-20626 MTC-67 H.V.	U A N	364-20627 MTC-76 L.V.	U A N	364-20628 MTC-76 H.V.	U A N	364-20629 MTC-67 L.V.	U A N	364-20630 MTC-67 H.V.	U A N	364-20631 MTC-76 L.V.	U A N	364-20632 MTC-76 H.V.	U A N
301	DEVICE, PRE-ROTATION	364-15250	1	364-15250	1	364-15249	1	364-15249	1	364-15250	1	364-15250	1	364-15249	1	364-15249	1
302	WASHER, TERM. BOLT (SPECIAL)	064-09289	6	064-12740	3	064-09289	6	064-12740	3	064-09289	6	064-12740	3	064-09289	6	064-12740	3
303	RING, SEAL IMPELLER	064-20430	1	064-20430	1	064-20431	1	064-20431	1	064-20430	1	064-20430	1	064-20431	1	064-20431	1
304	WASHER, FLAT SPRING	064-06242	1	064-06242	1	064-05741	1	064-05741	1	064-06242	1	064-06242	1	064-05741	1	064-05741	1
305	PLATE, NOZZLE BASE	064-20409	1	064-20409	1	064-20410	1	064-20410	1	064-20409	1	064-20409	1	064-20410	1	064-20410	1
306	PLATE, DIFFUSER	064-11810	1	064-11810	1	064-11638	1	064-11638	1	064-11810	1	064-11810	1	064-11638	1	064-11638	1
307	IMPELLER	064-11297	1	064-11297	1	064-11127	1	064-11127	1	064-11297	1	064-11297	1	064-11127	1	064-11127	1
308	RING, RETAINING OIL SEAL	064-06243	1	064-06243	1	064-05742	1	064-05742	1	064-06243	1	064-06243	1	064-05742	1	064-05742	1
309	BOLT, TERMINAL	064-14953	6	064-14970	3	064-14953	6	064-14970	3	064-14953	6	064-14970	3	064-14953	6	064-14970	3
310	BUSHING, TERM. BOLT	025-11107*	12	025-08586†	6	025-11107*	12	025-08586†	6	025-11107*	12	025-08586†	6	025-11107*	12	025-08586†	6
311	RING, TERM. BOLT	029-08527*	12	028-03896†	6	029-08527*	12	028-03896†	6	029-08527*	12	028-03896†	6	029-08527*	12	028-03896†	6
312	RING, PACKING TERM. BOLT	028-04975*	6	028-03897†	3	028-04975*	6	028-03897†	3	028-04975*	6	028-03897†	3	028-04975*	6	028-03897†	3
313	PLATE, INSULATING	025-10288	12	025-10289	6	025-10288	12	025-10289	6	025-10288	12	025-10289	6	025-10288	12	025-10289	6
314	BAR, LOCKING TERM. BOLT	025-10287	1	025-10286	1	025-10287	1	025-10286	1	025-10287	1	025-10286	1	025-10287	1	025-10286	1
315	BAR, ELECT. BUS	064-14972	6	064-14986	3	064-14972	6	064-14986	3	064-14972	6	064-14986	3	064-14972	6	049-14986	3
316	BAR, ELECT. JUMPER	SEE SALES ORDER	3	---	---	SEE SALES ORDER	3	---	---	SEE SALES ORDER	3	---	---	SEE SALES ORDER	3	---	---
317	BAR, ELECT. INTERNAL	064-14974	6	---	---	064-14974	6	---	---	064-14974	6	---	---	064-14974	6	---	---
318	NUT, JAM HEX	021-11500	12	021-00589	6	021-11500	12	021-00589	6	021-11500	12	021-00589	6	021-11500	12	021-00589	6
319	HOUSING, MOTOR	064-17843	1	064-17844	1	064-17843	1	064-17844	1	064-17843	1	064-17844	1	064-17843	1	064-17844	1
320	SCR. CAP 12 PT.HD. 3/8-16UNC X 1 3/4 LG.	021-11916	6	021-11916	3	021-11916	6	021-11916	3	021-11916	6	021-11916	3	021-11916	6	021-11916	3
321	NUT, HEX 3/8	021-00466	14	021-00466	5	021-00466	14	021-00466	5	021-00466	12	021-00466	3	021-00466	12	021-00466	3
322	WASHER, PLAIN 1 3/32 ID	021-01274	12	021-01274	3	021-01274	12	021-01274	3	021-01274	12	021-01274	3	021-01274	12	021-01274	3
323	WASHER, PLAIN	021-05172	6	068-00142	3	021-05172	6	068-00142	3	021-05172	6	068-00142	3	021-05172	6	068-00142	3
324	WASHER, SPL.	064-12740	6	---	---	064-12740	6	---	---	064-12740	6	---	---	064-12740	6	---	---
325	SCR. CAP 12 PT.HD. 3/8-16UNC X 1 1/8 LG.	021-11148	6	---	---	021-11148	6	---	---	021-11148	6	---	---	021-11148	6	---	---
326	SCR. CAP, HEX HD. 1/4-20UNC X 1 LG.	SEE SALES ORDER	12	---	---	SEE SALES ORDER	12	---	---	SEE SALES ORDER	12	---	---	SEE SALES ORDER	12	---	---
327	NUT, HEX, 1/4-20UNC	SEE SALES ORDER	12	---	---	SEE SALES ORDER	12	---	---	SEE SALES ORDER	12	---	---	SEE SALES ORDER	12	---	---
328	WASHER, PLAIN 9/32ID X 5/8OD X .065 TH.	SEE SALES ORDER	24	---	---	SEE SALES ORDER	24	---	---	SEE SALES ORDER	24	---	---	SEE SALES ORDER	24	---	---
331	TERM. ELECT. 1/8 N. P. T.	025-09346	2	---	---	025-09346	2	---	---	025-09346	2	---	---	025-09346	2	---	---
332	BUSHING, PIPE	068-09057	2	---	---	068-09057	2	---	---	068-09057	2	---	---	068-09057	2	---	---
333	LEVER, P. R. DEVICE (EXT.)	064-12237	1	064-12237	1	064-12237	1	064-12237	1	064-16836	1	064-16836	1	064-16836	1	064-16836	1
334	SCR. CAP	021-11149	3	021-11149	3	021-11149	3	021-11149	3	021-02750	3	021-02750	3	021-02750	3	021-02750	3
335	LINK, EXT. HAND	064-12235	1	064-12235	1	064-12235	1	064-12235	1	---	---	---	---	---	---	---	---
336	TUBING, FILLPIECE	064-15003	1	064-15003	1	064-15003	1	064-15003	1	---	---	---	---	---	---	---	---
337	SCR. CAP	021-11741	4	021-11741	4	021-11741	4	021-11741	4	021-08310	3	021-08310	3	021-08310	3	021-08310	3
338	PLATE MOTOR SUPPORT	364-12236	1	364-12236	1	364-12236	1	364-12236	1	064-20428	1	064-20428	1	064-20428	1	064-20428	1
339	SCR. CAP	021-11940	1	021-11940	1	021-11940	1	021-11940	1	021-02399	1	021-02399	1	021-02399	1	021-02399	1
340	MOTOR, INDUSTRIAL	025-09360	1	025-09360	1	025-09360	1	025-09360	1	024-09599	1	024-09599	1	024-09599	1	024-09599	1
342	BOLT, SHOULDER	064-12815	1	064-12815	1	064-12815	1	064-12815	1	---	---	---	---	---	---	---	---

* PARTS INCLUDED IN KIT 464-21460 † PARTS INCLUDED IN KIT 464-21461