

VARIABLE COMPONENTS

ITEM NO.	DESCRIPTION	ELECTRIC P. R. V. MOTOR							
		LINE NO. 1	Q	LINE NO. 2	Q	LINE NO. 3	Q	LINE NO. 4	Q
		364-20220 LTB67 ARR'G'T#1	U A N	364-20221 LTB67 ARR'G'T#2	U A N	364-20222 LTB76 ARR'G'T#1	U A N	364-20223 LTB76 ARR'G'T#2	U A N
202	DEVICE, PRE-ROTATION	364-15250	1	364-15250	1	364-15249	1	364-15249	1
203	RING, SEAL IMPELLER	064-20430	1	064-20430	1	064-20431	1	064-20431	1
204	WASHER, FLAT SPRING	064-06242	1	064-06242	1	064-05741	1	064-05741	1
205	PLATE, NOZZLE BASE	064-20409	1	064-20409	1	064-20410	1	064-20410	1
206	PLATE, DIFFUSER	064-11810	1	064-11810	1	064-11638	1	064-11638	1
207	IMPELLER	064-11297	1	064-11297	1	064-11127	1	064-11127	1
208	RING, RETAINING OIL SEAL	064-06243	1	064-06243	1	064-05742	1	064-05742	1
210	GLASS, OIL SIGHT	-----	1	026-13123	1	-----	1	026-13123	1
211	CONTROL OIL FLOAT SWITCH	025-10017	1	-----	1	025-10017	1	-----	1
216	TUBING, FILLPIECE	064-15003	1	064-15003	1	064-15003	1	064-15003	1
217	SCREW, CAP	021-11940	1	021-11940	1	021-11940	1	021-11940	1
218	LEVER P. R. DEVICE	064-12237	1	064-12237	1	064-12237	1	064-12237	1
219	PLATE, MOTOR SUPPORT	364-12236	1	364-12236	1	364-12236	1	364-12236	1
220	BOLT, SHOULDER (SPEC.)	064-12815	1	064-12815	1	064-12815	1	064-12815	1
221	SCREW, CAP	021-11149	3	021-11149	3	021-11149	3	021-11149	3
222	LINK, EXTERNAL	064-12235	1	064-12235	1	064-12235	1	064-12235	1
223	NUT, HEX 3/8	021-00466	2	021-00466	2	021-00466	2	021-00466	2
224	MOTOR, IND.	025-09360	1	025-09360	1	025-09360	1	025-09360	1
225	RING, "O" 2 OD X 1.799 ID . 103 THK	-----	1	028-07407	1	-----	1	028-07407	1
226	SCREW, CAP	021-11741	4	021-11741	4	021-11741	4	021-08310	4

VARIABLE COMPONENTS

ITEM NO.	DESCRIPTION	AIR P. R. V. MOTOR							
		LINE NO. 5	Q	LINE NO. 6	Q	LINE NO. 7	Q	LINE NO. 8	Q
		364-20224 LTB67 ARR'G'T#1	U A N	364-20225 LTB67 ARR'G'T#2	U A N	364-20226 LTB76 ARR'G'T#1	U A N	364-20227 LTB76 ARR'G'T#2	U A N
202	DEVICE, PRE-ROTATION	364-15250	1	364-15250	1	364-15249	1	364-15249	1
203	RING, SEAL IMPELLER	064-20430	1	364-15250	1	064-20431	1	064-20431	1
204	WASHER, FLAT SPRING	064-06242	1	064-06242	1	064-05741	1	064-05741	1
205	PLATE, NOZZLE BASE	064-20409	1	064-20409	1	064-20410	1	064-20410	1
206	PLATE, DIFFUSER	064-11810	1	064-11810	1	064-11638	1	064-11638	1
207	IMPELLER	064-11297	1	064-11297	1	064-11127	1	064-11127	1
208	RING, RETAINING OIL SEAL	064-06243	1	064-06243	1	064-05742	1	064-05742	1
210	GLASS, OIL SIGHT /	-----	1	026-13123	1	-----	1	026-13123	1
211	CONTROL OIL FLOAT SWITCH	025-10017	1	-----	1	025-10017	1	-----	1
216	TUBING, FILLPIECE	-----	1	-----	1	-----	1	-----	1
217	SCREW, CAP	021-02399	1	021-02399	1	021-02399	1	021-02399	1
218	LEVER P. R. DEVICE	064-16836	1	064-16836	1	064-16836	1	064-16836	1
219	PLATE, MOTOR SUPPORT	064-20428	1	064-20428	1	064-20428	1	064-20428	1
220	BOLT, SHOULDER (SPEC.)	-----	1	-----	1	-----	1	-----	1
221	SCREW, CAP	021-02750	3	021-02750	3	021-02750	3	021-02750	3
222	LINK, EXTERNAL	-----	1	-----	1	-----	1	-----	1
223	NUT, HEX 3/8	-----	1	-----	1	-----	1	-----	1
224	MOTOR, IND.	024-09599	1	024-09599	1	024-09599	1	024-09599	1
225	RING, "O" 2 OD X 1.799 ID . 103 THK	-----	1	028-07407	1	-----	1	028-07407	1
226	SCREW, CAP	021-08310	3	021-08310	3	021-08310	3	021-08310	3