

**CONTROL CENTER VARIATIONS AND  
PART NUMBERS**

CONTROL CENTER VARIATION	MODEL TURBOPAK	OIL PUMP VOLTS-PHASE-HERTZ	CONTROL CENTER PART NUMBER			
			MANUAL RESTART		AUTOMATIC RESTART	
For use with electro mechanical starter low voltage (208V-600V) motors	HT/OT YT	208, 220, 230 240-3-60	366-82177-047		366-82177-052	
		440, 460 480-3-60		-048		-053
		550,575,600-3-60		-049		-054
		380, 416-3-60 380, 400, 415-3-50		-050		-055
		220-3-50		-043		-045
		346-3-50		-051		-056
		440-3-50		-044		-046
High voltage (2300V-4160V) For use with electro mechanical starter	HT	208, 220 230, 240-3-60		-011		-016
		440, 460, 480-3-60		-012		-017
		550, 575, 600-3-60		-013		-018
		380, 416-3-60 380, 400, 415-3-60		-014		-019
		220-3-50		-009		-021
		346-3-50		-015		-020
		440-3-50		-010		-022
For use with Solid State Starter (low voltage 206V-600V motors)	HT/OT	208, 220, 230, 240-3-60		-029		-033
		440, 460, 480-3-60		-030		-034
		550, 575, 600-3-60		-031		-035
		380, 400, 415-3-50		-032		-036
For use with Solid State Starter with transformer (low voltage 208V-600V motors)	HT/OT	208-3-60		-057		-061
		440, 460, 480-3-60		-058		-062
		550, 575, 600-3-60		-059		-063
		380, 400, 415-3-60		-060		-064
		220, 230, 240-3-60		-065		-066
For use with Solid State Starter with transformer	HY/YT	208-3-60		-177	Separate Automatic Restart Kit Part No. 366-89592A	
		440, 460, 480-3-60		-178		
		550, 575, 600-3-60		-179		
		380, 400, 415-3-60		-180		
		220, 230, 240-3-60		-181		