

**SOLID STATE STARTER (OPTIONAL)
TRANSFORMER FUSE AND FUSE HOLDER
SEE FIGS. 4 & 6**

ITEM	DESCRIPTION	208V		220V, 230V, 240V, 440V, 460V, 480V		550V, 575V, 600V		400V, 415V, 380V		SEE FIG.
		PART NO.	QUAN.	PART NO.	QUAN.	PART NO.	QUAN.	PART NO.	QUAN.	
45	Transformer	025-17770	1	025-17224	1	025-14250	1	025-19498	1	4
46	Fuse	025-20785	1	025-20785	1	025-20785	1	025-20785	1	6
47	Fuse Holder	025-20786	1	025-20786	1	025-20786	1	025-20786	1	6

**OIL PUMP STARTER
HEATER ELEMENTS (REFER TO FIG. 4)**

VOLTS – PHASE – HERTZ	PART NO.	QUAN.
208, 220, 230, 240-3-60	024-19428	3
440, 460, 480-3-60	024-18424	3
550, 575, 600-3-60	024-19444	3
380, 416-3-60	024-20092	3
380, 400, 415-3-50		
220-3-50	024-19424	3
346-3-50	024-19420	3
440-3-50	024-20799	3

York International Corporation
Applied Systems
Post Office Box 1592-36BE
York Pennsylvania 17403-1592
Telephone 717 771 7890

YORK®