

Compressor Common Parts List

Item	Part Description	HERMETIC MTH 67 & 76		OPEN LTH 67 & 76		HERMETIC MTH 85 & 95		OPEN LTH 85 & 95	
		Part No.	Quan.	Part No.	Quan.	Part No.	Quan.	Part No.	Quan.
115	Bracket, Motor Mounting	—	—	—	—	364-32605	1	364-32605	1
116	Control, Temperature (Hot)	025-15381-002	1	025-15381-002	1	025-15381-002	1	025-15381-002	1
117	Elbow Cinch, 45° 3/4" Tube x 3/4" NPTE	023-07264	2	023-07264	2	023-07264	2	023-07264	2
118	Tube, 3/4" O.D. x .049" Wall	064-46069	1	064-46069	1	064-46068	1	064-46068	1
119	Lockwasher, Spring 1/2"	—	—	—	—	021-05271	1	021-05271	1
120	Fillpiece	—	—	—	—	064-09069	1	064-09069	1
121	Compressor, Sealer GR-AVV	013-01671	A.R.	013-01671	A.R.	013-01671	A.R.	013-01671	A.R.
122	—	—	—	—	—	—	—	—	—
123	Sealant	013-01678	A.R.	—	—	013-01678	A.R.	013-1678	A.R.
124	Gasket, Hand Hole Cover ▲	064-22039	1	—	—	064-22039	1	—	—
125	Plate, Handhole	064-21997	1	—	—	064-21997	1	—	—
126	Screw, Cap Hex Hd. 3/8"—16 x 1" Lg.	021-01477	8	—	—	021-01477	8	—	—
127	Box, Electric Oct.	025-10290	1	—	—	025-10290	1	—	—
128	Cover, Electric Box	025-10291	1	—	—	025-10291	1	—	—
129	Gasket, Handhole Cover ▲	*070-07509	1	—	—	*070-07509	1	—	—
130	Cover, Handhole	064-46035	1	—	—	064-46035	1	—	—
131	Ring, Shaft Retainer	064-46156	1	—	—	064-46156	1	—	—
132	Plate, Retaining Ring	064-46147	1	—	—	064-46147	1	—	—
133	Ring, External Retaining	029-16865	2	—	—	029-16865	2	—	—
134	Screw, Machine 1/4"—20 x 3/4"	021-01898	4	—	—	021-01898	4	—	—
135	Key, Special ▲	064-46186	1	—	—	064-46186	1	—	—
136	Plug, Liquid Seal	064-46144	1	—	—	064-46144	1	—	—
137	Seal "O" Ring 1-3/8" x 1/8" Sect. ▲	028-08633	1	—	—	028-08633	1	—	—
138	Screw, Cap 12 Pt. Hd. 5/16"—18 x 1-1/2" Lg.	021-11142	4	—	—	021-11142	4	—	—
139	Washer, Conical ▲	021-15545	4	—	—	021-15545	4	—	—
140	Plug, Stator Locking	064-12161	1	—	—	064-12161	1	—	—
141	Seal, "O" Ring 15/16" I.D. x 3/32" Sect.	028-05403	1	—	—	028-05403	1	—	—
142	Housing, Motor	See Page 10 Table 1, Item 218	1	—	—	See Page 13 Table 3, Item 219	1	—	—
143	Plug Pipe, 1/4"—18 NPTE	023-01972	2	—	—	023-01972	4	—	—
144	Support, Bearing Terminal End	064-45997	1	—	—	064-45997	1	—	—
145	Cover, Liquid Seal	See Page 10 Table 1, Item 216	1	—	—	See Page 13 Table 3, Item 239	1	—	—
146	Gasket, Cover Liquid Seal ▲	064-45992	1	—	—	*064-45992	1	—	—
147	Screw, Cap Hex Hd. 3/8"—16 x 1" Lg.	021-01477	34	—	—	021-01477	34	—	—
148	Gasket, Bearing Support Terminal End ▲	064-16871	1	—	—	*064-16871	1	—	—
149	Ring, Seal ▲	064-11997	2	—	—	*064-11997	2	—	—
150	Ring, Retainer Internal	029-08498	2	—	—	029-08498	2	—	—
151	Washer, Flat Spring	064-12001	2	—	—	064-12001	2	—	—
152	Pipe Plug 1/8"—27 NPTE	023-01969	2	—	—	023-01969	2	—	—
153	Bearing, Motor ▲	064-46155	1	—	—	*064-46155	1	—	—
154	Ring, Internal Retaining	029-13615	1	—	—	029-13615	1	—	—
155	Stator	See Nameplate	1	—	—	See Nameplate	1	—	—
156	Rotor, Hermetic Motor	See Page 10 Table 1, Item 219	1	—	—	See Page 13 Table 3, Item 217	1	—	—
157	Insulation, Thermal	See Page 10 Table 1, Item 227	2	—	—	See Page 13 Table 3, Item 235	2	—	—
158	Insulation, Thermal	See Page 10 Table 1, Item 233	1	—	—	See Page 13 Table 3, Item 229	1	—	—
159	Bar Shaft, Coupling	064-46119	2	—	—	064-46119	2	—	—
160	Strap, Cable	See Page 10 Table 1, Item 226	1	—	—	See Page 13 Table 3, Item 228	1	—	—
161	Screw, Machine Rd. Hd. Recd. 10—24 x 1/2" Lg.	See Page 10 Table 1, Item 228	1	—	—	See Page 13 Table 3, Item 226	1	—	—
162	Tubing, Electrical Insulating	See Page 10 Table 1, Item 217	1	—	—	See Page 13 Table 3, Item 217	1	—	—
163	Terminal, Pushon	025-06642	4	—	—	025-06642	4	—	—
164	Varnish, Scotch Cast Resin	013-01016	A.R.	—	—	013-01016	A.R.	—	—
165	Label, Caution	See Page 10 Table 1, Item 237	1	—	—	See Page 13 Table 3, Item 201	1	—	—
166	Terminal, Electric 1/4" NPTE	025-18134	4	—	—	025-18134	4	—	—
167	Box, Terminal	364-42276	1	—	—	364-42276	1	—	—
168	Support End, Terminal Box	064-45893	1	—	—	064-45893	1	—	—
169	Screw, Cap 3/8"—16 x 5/8" Lg.	021-08333	4	—	—	021-08333	4	—	—
170	Cover, Electrical End Support	See Page 10 Table 1, Item 233	1	—	—	See Page 13 Table 3, Item 233	1	—	—

▲ Motor Bearing and Seal Kit, MTH 67, 76, 85 and 95, Part No. 464-46502.

A.R. — As Required.