

# HERMETIC COMPRESSOR VARIABLE PARTS LIST

YORK DIVISION BORG-WARNER

Item	Description	Model MKA-65 (L.V.) 364-24168		Model MKA-73 (L.V.) 364-24169		Model MKA-65 (H.V.) 364-24170		Model MKA-73 (H.V.) 364-24171	
		Part No.	Quan.	Part No.	Quan.	Part No.	Quan.	Part No.	Quan.
200	Common Parts	See Pg. 10 & 11	—	See Pg. 10 & 11	—	See Pg. 10 & 11	—	See Pg. 10 & 11	—
201	Support, Rotor	064-24128	1	064-24129	1	064-24128	1	064-24129	1
202	Scroll, Rotor	064-23755	1	064-23754	1	064-23755	1	064-23754	1
203	Collar, Thrust (Pinion)	064-24130	1	064-24131	1	064-24130	1	064-24131	1
204	Impeller	064-23824	1	064-23825	1	064-23824	1	064-23825	1
205	Ring, Impeller Seal	064-23977	1	064-23980	1	064-23977	1	064-23980	1
206	Washer, Flat Spring	064-23978	1	064-23981	1	064-23978	1	064-23981	1
207	Ring, Internal Retaining	064-23979	1	064-23982	1	064-23979	1	064-23982	1
208	Plate, Impeller Seal Retaining	064-23726	1	064-23727	1	064-23726	1	064-23727	1
209	Gasket, Retaining Plate	*064-24122	1	*064-24123	1	*064-24122	1	*064-24123	1
210	Device, P.R.V.	364-27407	1	364-27408	1	364-27407	1	364-27408	1
211	Bar, Jumper	See Sales Ord.	3	See Sales Ord.	3	—	—	—	—
212	Box, Electrical Octagon	025-10290	1	025-10290	1	—	—	—	—
213	Cover, Box, Electrical Octagon	025-10291	1	025-10291	1	—	—	—	—
214	Terminal, Push-on, Female	025-06642	4	025-06642	4	025-06466	4	026-06466	4
215	Terminal, Electrical 1/8 NPT	025-09346	4	025-09346	4	025-15923	4	025-15923	4
216	Gasket, Round 1-5/16 O.D. X 7/8 I.D. X 1/16 thk.	—	—	—	—	028-08356	3	028-08356	3
217	Ring "O" 1-9/64 O.D. X 22/64 I.D. X 9/64 Sect.	028-07761	6	028-07761	6	028-07761	3	028-07761	3
218	Ring "O" 1-41/64 O.D. X 1-23/64 I.D. X 9/64 Sect.	028-07760	6	028-07760	6	028-07760	3	028-07760	3
219	Bushing, Terminal Bolt	025-14468	6	025-14468	6	025-16000	3	025-16000	3
220	Plate, Insulating	025-14470	12	025-14470	12	025-14470	6	025-14470	6
221	Washer, Plain	021-05157	6	021-05157	6	021-05157	3	021-05157	3
222	Nut, Jam Hex.	021-11608	12	021-11608	12	021-11608	6	021-11608	6
223	Bolt, Terminal	064-22992	6	064-22992	6	064-22992	3	064-22992	3
224	Connector, Terminal	064-23092	6	064-23092	6	064-23092	3	064-23092	3
225	Nut, Hex 3/8 — 16 UNC—3B	021-00466	6	021-00466	6	021-00466	3	021-00466	3
226	Washer, Plain	021-01274	6	021-01274	6	021-01274	3	021-01274	3
227	Bar, Locking	025-14558	2	025-14558	2	025-14558	1	025-14558	1
228	Washer, Terminal Bolt	064-12740	6	064-12740	6	064-12740	3	064-12740	3
229	Screw, Cap 12 Pt. Hd. 3/8 — 16 UNC—3A	021-11920	6	021-11920	6	021-11920	3	021-11920	3
230	Housing, Motor	064-24194	1	064-24194	1	064-24707	1	064-24707	1

\* — Parts Included Field Replacement Kit — 364-34337