



# AUXILIARY CONTROL BOX



NOTE: Unit less transfer unit do not contain items 2 & 4.

FIG. 10—LOW VOLTAGE AUXILIARY CONTROL BOX & HT TURBOPAKS ONLY



NOTE: Units less transfer unit do not contain item 2 & 4.

FIG. 11—HIGH VOLTAGE AUXILIARY CONTROL BOX & OT TURBOPAKS