

## PNEUMATIC CONTROL CENTER

Item	Part Description	Fig.	Quan.	Part No.	
				Standard** 366-80910-002	Low Temp.** 366-80910-003
1	Controller, Temperature (TC)	4	1	026-16196	026-16196
2	Current Limit Relay (Transducer) (CLR)	4	1	324-15335-001	324-15335-001
3	Restrictor, Variable Adjustable	4	1	026-15426	026-15426
4	Valve, Prv Air Solenoid (1 SOL)	4	1	325-11931-001	325-11931-001
5	Controller, Load Limiting (LLC)	4	1	025-17362	025-17362
6	Plug, Pipe 1/8 NPT	4	2	023-01182	023-01182
7	Control, Oil Pressure (OP)	4	1	025-14386	025-14386
8	Control, High Pressure (HP)	4	1	025-17289	025-17289
9	Control, Low Pressure (LP)	4	1	225-15929-002	225-15929-004
10	Relay, Control, RBM91 (14R)	4	1	024-11655	024-11655
11	Relay, Control, RBM92 (11R)	4	1	024-11784	024-11784
12	Relay, Control, RBM91 (6R, 7R, 8R, 9R)	4	4	024-17075	024-17075
13	Block, Terminal (Push-On Terminal)	4,5	36	025-15865	025-15865
14	Block, Terminal, End	4,5	2	025-13981	025-13981
15	Timer (2TR)	4	1	025-17626	025-17626
16	Timer, Repeat Cycle (1TR)	4	1	025-17172	025-17172
17	Transformer (2T)	4	1	325-16601-002	325-16601-002
18	Strip, Marker	4	1	025-20517	025-20517
19	Strip, Marker	4	1	025-20518	025-20518
20	Gauge, Pressure (HP)	4,7	1	026-14572-005	026-14572-005
21	Gauge, Pressure (OP)	4,7	1	026-14572-001	026-14572-001
22	Gauge, Pressure (LP)	4,7	1	026-14572-003	026-14572-003
23	Gauge, Pressure (Air)	4,7	2	026-16195	026-16195
24	Panel, Center	6	1	366-40651	366-40651
25	Light, Indicator (Red) (L-4—L-7)	6,8	4	025-13551	025-13551
26	Light, Indicator (Amber) (L2-3, L8, L9-12)	6,8	4	025-14025	025-14025
27	Fuseholder	6,8	4	025-13991	025-13991
28	Fuse, 1/2 AMP, 250V, CTG (4FU)	6,8	1	025-14383	025-14383
29	Fuse, 15 AMP, 250V, CTG (1FU-3FU)	6,8	3	025-14384	025-14384
30	Switch, Pushbutton, Black	6,8	1	024-13761	024-13761
31	Switch, Pushbutton, Red	6,8	1	024-16933	024-16933
32	Switch, Rocker (Service)	6,8,4	2	024-13760	024-13760
33	Resistor, Variable	8	1	025-15890	025-15890
34	Screw, Slot Hd., No. 2	6	1	021-11631	021-11631
35	Washer, Retaining No. 2	6	1	021-11632	021-11632
36	Relay, Control RBM91 (4R, 17R)	4	2	024-14519	024-14519
37	Fastener, Lock and Key	4	1	021-13025	021-13025
38	Restrictor, Pneumatic	4	1	026-16208	026-16208
39	*Tube, Plastic 1/4 O.D. x .040 x 6 Lg.	4	1	067-32310	067-32310
40	*Tube, Plastic 1/4 O.D. x .040 x 6-1/2 Lg.	4	1	066-20823	066-20823
41	*Tube, Plastic 1/4 O.D. x .040 x 8-1/2 Lg.	4	1	066-17027	066-17027
42	*Tube, Plastic 1/4 O.D. x .040 x 10 Lg.	4	2	066-17028	066-17028
43	*Tube, Plastic 1/4 O.D. x .040 x 14 Lg.	4	1	066-17029	066-17029
44	*Tube, Plastic 1/4 O.D. x .040 x 18 Lg.	4	1	066-17030	066-17030
45	*Tube, Plastic 1/4 O.D. x .040 x 20-1/2 Lg.	7	1	066-17031	066-17031
46	Door Control Panel	4	1	367-82337	367-82337
47	Relay, Control RBM91 (5R)	4	1	024-12951	024-12951
48	Relay, Control RBM92 (3R) (10R)	4	1	024-17093	024-17093
49	Shaft, Flex. and Panel Bearing	8	1	025-15891	025-15891
50	Pressure Regulator	9	1	022-03533	022-03533
51	Gauge	9	1	026-10301	026-10301
52	Light Indicator (White) (L-1, 10, 11)	6	3	025-15708	025-15708
53	Switch, Rocker (Oil)	4,6,8	1	024-16590	024-16590

\*Use plastic polyethylene material 1/4 in. O.D. x .040 in. wall, natural, 500 ft. spool, Part No. 028-04589.

\*\*Latest production models.