

TABLE 5 (CONT'D)— COMPRESSOR TOOLS

TOOL DESCRIPTION	COMPRESSOR - TOOL PART NO.					
	LTD-95	LTD 95 (1 1/2 X 1 1/4 COUPLING)	LTD 108	LTD 108 (1 7/8 X 1 1/2 COUPLING)	LTD 120	LTD 120 (1 7/8 X 1 1/2 COUPLING)
COMPLETE TOOL KIT	464-18724	464-24521	464-25730	464-25753	464-25730	464-25753
<i>Coupling</i> WRENCH, FOR HOLDING COMPR. SHAFT	(2) 364-06619	(1) 364-06619 (1) 364-16731	364-16731	364-16731 364-14916	364-16731	364-16731 364-14916
WRENCH, FOR REMOVAL OF HIGH SPEED OIL PUMP CONSISTING OF: TOOL, OIL PUMP PINS BAR-WRENCH HANDLE	064-21481 (2) 064-20376 064-13584	064-21481 (2) 064-20376 064-13584	064-25581 (4) 064-20376 064-13583	064-25581 (4) 064-20376 064-13583	064-25581 (4) 064-20376 064-13583	064-25581 (4) 064-20376 064-13583
EYEBOLTS, 3/4" 7/8"	(1) 021-00307	(1) 021-00307	(2) 021-00307 (2) 021-07703	(2) 021-00307 (2) 021-07703	(2) 021-00307 (2) 021-07703	(2) 021-00307 (2) 021-07703
GUIDE STUDS, 5/8" X 7 1/2" LG.	(3) 064-06798	(3) 064-06798	(3) 064-06798	(3) 064-06798	(3) 064-06798	(3) 064-06798
PIN, 3/8" X 7 1/2" LG.	064-18716	064-18716	064-18716	064-18716	064-18716	064-18716
STUD, PRV REMOVAL AND TWO NUTS, 1/2 - 20 - UNF	064-14500 (2) 021-00483	064-14500 (2) 021-00483	064-14500 (2) 021-00483	064-14500 (2) 021-00483	064-14500 (2) 021-00483	064-14500 (2) 021-00483
BAR, 1/2" DIA. X 7" LG.	064-17327	064-17327	—	—	—	—
BAR, HEX FOR H. S. SHAFT	064-28204	064-28204	064-17715	064-17715	064-17715	064-17715
THREAD, COMPOUND	464-14934	464-14934	464-14934	464-14934	464-14934	464-14934
SCREW, SET HEX, SOCKET 1/2 - 20 UNF X 1" LG.	—	—	(4) 021-12234	(4) 021-12234	(4) 021-12234	(4) 021-12234

41

TABLE 6— TOOLS

DESCRIPTION	PART NO.
PLIERS, WALDLES TRUARC. NO. 5	029-08590
PLIERS, WALDLES TRUARC. NO. 7	029-07934
HAND OIL PUMP	070-10654
HAND OIL PUMP SEAL	026-10904

TABLE 7— LUBRICANTS, OILS AND COMPOUNDS

DESCRIPTION	PART NO.
THREAD COMPOUND, ARI HIGH PRESSURE- 1/4 PT. CAN	464-14934
COATING LUBRICANT-MOLYKOTE, TYPE Z - 2 OZ. CAN	364-21508
OIL, YORK REFRIGERATION-TYPE B, - 5 GAL. CAN	011-00309