



**CONTROL CENTER AND ELECTRICAL AND PNEUMATIC COMPONENTS**



**FIG. 70—** Low Water Temperature Thermostat



**FIG. 71 —** Temperature Control Sensor



**FIG. 72—** Low Water Temperature Transmitter -  
Pneumatic PRV Control - Units Only

ITEM	DESCRIPTION	QUAN.	PART NO.	FIG.
1	LOW WATER TEMPERATURE THERMOSTAT PENNA-A 19ABC-23-RANGE 20 F TO 80 F	1	025-14464	70
2	TEMPERATURE CONTROL SENSOR HONEYWELL-7025A-1090	1	025-10439	71
3	LOW WATER TEMPERATURE TRANSMITTER JOHNSON SERVICE-T-5210-134 RANGE 32 F-57 F (PNEUMATIC CONTROL ONLY)	1	022-03481	72