

MODELS HT90 THRU HT640





FIG. 2— MODEL OT 290 TURBOPAK – REAR VIEW

TABLE 1— BASIC UNIT PARTS

ITEM	PART DESCRIPTION	QUAN.	PART NUMBER			
			OT90 THRU OT130	OT150 THRU OT230	OT260 THRU OT360	OT390 THRU OT640
1	GASKET, SUCTION CONNECTION	2	028-08778-001	028-08778-002	028-08778-003	028-08778-004
2	GASKET, DISCHARGE	1	070-12343	070-12208	070-10630	070-10633
3	BURSTING, DISC	1	026-09353	026-09353	026-09353	026-09353
4	GASKET, BURSTING DISC	2	070-15845	070-15845	070-15845	070-15845
5	ISOLATOR	7	028-02162	028-02162	028-02162	028-02162
6	SOLENOID VALVE	1	025-16914	025-16914	025-16914	025-16914
7	DEHYDRATOR	1	026-14777-007	026-14777-007	026-14777-007	026-14777-007
8	EDUCTOR, OIL RETURN	1	364-18241	364-18241	364-18241	364-18241
9	MOTOR	1	SEE DATA NAMEPLATE	SEE DATA NAMEPLATE	SEE DATA NAMEPLATE	SEE DATA NAMEPLATE