

OPEN COMPRESSOR PARTS LIST (CONTINUED)

Item No.	Description	Model 53-59		Model 67-76		Model 85-95		Model 108-120	
		YORK Part No.	Quan.	YORK Part No.	Quan.	YORK Part No.	Quan.	YORK Part No.	Quan.
76	Special Connection	064-07937	1	064-07317	2	—	—	064-07315	2
77	Coupling, 5/8 Tube x 1/2 FPT	023-07342	1	—	—	—	—	—	—
78	Pipe Plug, Hex. Socket Head - 1/2	023-01994	3	023-01994	2	023-01994	3	023-01994	4
79	Pipe Plug, 1/4 - 18 NPT	023-01972	4	023-01972	4	023-01972	4	023-01972	4
80	Pipe Plug, 1"	—	—	—	—	—	—	023-05909	1
81	Pipe Plug, 1-1/4"	—	—	023-02015	3	—	—	—	—
82	Pipe Plug, 2"	023-02027	1	—	—	023-02027	2	023-02027	3
83	Pipe Plug, 3/8 (Sq. Hd.)	023-09908	1	023-09908	1	023-09908	1	023-09908	1
84	Pipe Plug, 3/4 - 14 NPT, Sq. Csk.	023-04208	2	—	—	—	—	—	—
85	Pipe Plug, 3/4 - NPT	—	—	023-04053	1	023-04053	1	—	—
86	Pipe Plug, 1/2 Sq. Hex.	—	—	023-03822	1	—	—	023-03822	1
87	Plug 1-1/16-12 UNF-2 With "O" Ring* (028-07848)	023-07063	1	023-07063	1	023-07063	1	023-07063	1
88	Flareless Plug With "O" Ring* (028-07759)	023-07158	1	023-07158	1	023-07158	1	—	—
89	Gasket	† 064-26781	1	■ 064-26781	1	● 064-26781	1	★ 064-26781	1
90	Oil Filter Cover	064-26780	1	064-26780	1	064-26780	1	064-26780	1
91	Tubing, 1/2 O.D. x .049 Wall	064-31771	1	064-31770	3	064-31498	1	—	—
92	Tubing, 3/8 O.D. x .049 Wall	064-31762	1	064-31762	1	064-31763	1	—	—
93	Tubing, 5/8 O.D. x .049 Wall	—	—	064-31777	2	064-31497	1	—	—
94	Tubing, 5/8 O.D. x .049 Wall	064-31777	1	064-31775	1	—	—	—	—
95	Tubing, 5/8 O.D. x .049 Wall	064-31776	1	064-21857	1	—	—	—	—
96	Connection - Vent Tube	064-15981	1	—	—	064-15533	1	—	—
97	Extension Tube	064-13895	1	064-14316	1	—	—	—	—
98	"O" Ring, 1-3/8 O.D. x 1-1/8 I.D. x 1/8 Sect.	† 028-04353	1	■ 028-04353	2	● 023-04353	1	★ 028-04353	1
99	"O" Ring, 1-7/8 O.D. x 1-5/8 I.D. x 1/8 Sect.	† 028-04861	1	■ 028-04861	1	—	—	—	—
100	"O" Ring, 1" O.D. x 7/8 I.D. x 1/16 Sect.	† 028-06932	1	—	—	—	—	—	—
103	"O" Ring, 1-1/4 O.D. x 1 I.D. x 1/8 Sect.	† 028-04522	2	■ 028-04522	2	● 028-04522	1	★ 028-04522	1
104	Adapter	064-20636	1	064-20636	1	—	—	—	—
105	Gasket, Oil Jet Pump	† 064-12101	1	■ 064-12101	1	—	—	—	—
106	Elbow, Screw 90° - 3/4 FPT	023-04313	2	023-04313	3	023-04313	1	023-04313	1
107	Elbow, Cinch 90°	023-06817	1	023-06817	1	023-06817	1	023-06817	1
109	Elbow, Screw 90° - 3/8 MPTI	023-04311	1	—	—	—	—	—	—
110	Elbow, 90°, 5/8 Tube x 1/2 MPT	023-06818	5	023-06818	2	023-06818	1	—	—
111	Elbow, 90°, 1/2 Tube x 3/8 MPT	023-06816	1	—	—	—	—	023-06816	1
112	Elbow, 45°, 3/8 Tube x 1/4 MPT	—	—	023-07092	1	—	—	—	—
113	Elbow, 45°, 1/2 Tube x 3/8 MPT	—	—	023-07172	2	023-07172	1	—	—
114	Elbow, 90°, 3/4 Tube x 3/4 FPT	—	—	023-08383	1	—	—	—	—
115	Elbow, 90°, 3/4 Tube x 3/4 MPT	—	—	023-06820	1	023-06820	4	023-06820	3

*Part of Field Replacement Kit

- † Parts included in Field Replacement Kit - Models LTD53 & LTD59 - Part No. 464-29624
- Parts included in Field Replacement Kit - Models LTD67 & LTD76 - Part No. 464-29626
- Parts included in Field Replacement Kit - Models LTD85 & LTD95 - Part No. 464-29628
- ★ Parts included in Field Replacement Kit - Models LTD108, LTD120 and LTD126 - Part No. 464-29630