

OPEN COMPRESSOR PARTS LIST (CONTINUED)

Item No.	Description	Model 53-59		Model 67-76		Model 85-95		Model 108-120	
		YORK Part No.	Quan.	YORK Part No.	Quan.	YORK Part No.	Quan.	YORK Part No.	Quan.
116	Elbow, Screw 45°, 3/4 NPTI x 3/4 NPTI	023-04321	1	—	—	—	—	023-04321	2
117	Elbow, 3/4 NPTI x 1/2 NPTI	023-04761	1	023-04761	1	023-04761	1	023-04761	1
118	Elbow, 90°, 1/4 Tube x 1/4 MPT	023-06813	1	—	—	—	—	—	—
119	Elbow, Street 90°, 3/8	—	—	—	—	023-05811	1	—	—
120	Elbow, Cinch Type 90°, 3/4 T x 3/4 T	—	—	—	—	—	—	023-09506	2
121	Elbow, Street, 90°, 3/4	—	—	—	—	023-06725	2	—	—
122	Connector, 3/4 Tube x 3/4 NPTI	023-08794	1	023-08794	1	023-08794	1	023-08794	1
123	Connector, 3/4 Tube x 3/4 MPT	023-06807	2	023-06807	1	023-06807	1	—	—
124	Connector, 3/8 Tube x 3/8 MPT	023-06802	1	—	—	—	—	—	—
125	Connector, 1/2 Tube x 3/8 MPT	—	—	023-06803	2	023-06803	1	023-06803	1
126	Connector, Cinch 1/2 MPT x 1/2 T	—	—	—	—	023-06804	1	023-06804	1
127	Connector, 5/8 O.D. x 1/2 NPTE	023-06805	1	023-06805	3	023-06805	1	023-06805	2
128	Connector, 3/8 Tube x 1/4 NPT	—	—	—	—	023-06801	1	—	—
129	Tee, Screw 3/4 x 3/4 x 1/2	023-04357	1	—	—	—	—	023-04357	2
130	Tee, Screw 3/4 x 3/8 x 3/4	023-04353	1	—	—	—	—	—	—
131	Tee, Screw 3/4 x 1/2 x 3/8	023-04832	2	023-04832	1	023-04832	1	—	—
132	Tee, Screw 3/4	—	—	023-04337	1	023-04337	1	—	—
133	Tee, Screw 3/4 x 1/2 x 1/2	—	—	—	—	—	—	023-04358	1
134	Tee, Screw 3/8 x 1/4 x 3/8	—	—	—	—	—	—	023-04344	1
135	Cross, 3/4 NPTI	—	—	023-04329	1	023-04329	1	—	—
136	Valve, Stop Angle 3/4	022-03850	3	022-03850	3	022-03850	3	022-03850	3
137	Bushing, 3/4 M.P.T. x 1/2 F.P.T.	—	—	023-04010	2	—	—	—	—
138	Valve, Stop Angle 3/8 Type 1	022-03849	1	022-03849	1	022-03849	1	022-03849	1
139	Valve, Stop Angle 1/4 Flare x 1/4 NPTE	022-03836	1	022-03836	1	022-03836	1	022-00009	1
140	Valve, Check 3/8 FPT(In) x 3/8 MPT-(Out)	022-02417	1	022-02417	1	022-02417	1	—	—
141	Valve, Check 3/8 MPT(In) x 3/8 MPT-(Out)	—	—	—	—	—	—	022-02042	1
142	Oil Filter	026-15749	1	026-15749	1	026-15749	1	026-13831	1
143	Oil Filter Element	† 026-14642	1	■ 026-14642	1	● 026-14642	1	★ 026-11225	1
144	Jet Oil Pump	364-13893	1	364-13873	1	364-13873	1	364-13880	1
145	Nipple, Pipe — 1/2 Sch. 80 x 1-1/8 Lg.	067-39601	2	067-39601	2	067-39601	2	067-39601	2
146	Nipple, Pipe — 3/4 Sch. 80 x 2 Lg.	070-16054	3	070-16054	1	—	—	—	—
147	Nipple, Pipe — 3/8 Sch. 80 x 1-1/2 Lg.	070-00806	1	—	—	—	—	—	—
148	Nipple, Pipe — 1/2 Sch. 80 x 2 Lg.	067-39603	1	—	—	—	—	—	—
149	Nipple, Pipe — 3/4 Sch. 80 x 1-3/8 Lg.	070-01541	2	070-01541	3	070-01541	1	070-01541	4
150	Nipple, Pipe — 3/4 Sch. 80 x 2-1/2 Lg.	—	—	—	—	070-11191	1	—	—
151	Nipple, Pipe — 3/4 Sch. 80 x 4-1/2 Lg.	—	—	070-01556	1	—	—	—	—
152	Nipple, Pipe — 3/4 Sch. 80 x 3 Lg.	—	—	—	—	070-16055	1	—	—
153	Nipple, Pipe — 3/4 Sch. 80 x 4 Lg.	—	—	070-12557	1	—	—	—	—
154	Nipple, Pipe — 3/4 Sch. 80 x 9 Lg.	—	—	—	—	—	—	—	—
155	Nipple, Pipe — 3/8 Sch. 80 x 1" Lg.	070-00773	1	—	—	—	—	—	—

† Parts included in Field Replacement Kit — Models LTD53 & LTD59 — Part No. 464-29624

■ Parts included in Field Replacement Kit — Models LTD67 & LTD76 — Part No. 464-29626

● Parts included in Field Replacement Kit — Models LTD85 & LTD95 — Part No. 464-29628

★ Parts included in Field Replacement Kit — Models LTD108, LTD120 and LTD126 - Part No. 464-29630