



FIG. 42 — COUPLING

ITEM	DESCRIPTION	LTD 53-59-50 HZ.		LTD 108, 120,126-50/60 HZ.		LTD 108, LTD 85&95-50/60 HZ.		LTD 108, 120,126-5 HZ.	
		1-1/4 x 1 364-27522		1-1/2 364-22205		1-1/2 x 1-1/4 364-24518		1-7/8 x 1-1/2 364-21794	
		Part No.	Quan.	Part No.	Quan.	Part No.	Quan.	Part No.	Quan.
1	Disk, CPLG (Drive)	064-18147	1	064-18134	1	064-18134	1	064-14386	1
2	Disk, CPLG (Driven)	064-27521	1	064-18133	1	064-24519	1	064-21793	1
3	Ring Clamp	064-24650	2	064-22204	2	064-22204	2	064-24651	2
4	Washer, CPLG	064-14393	6	064-13865	6	064-13865	6	064-13865	10
5	Screw	021-13189	3	021-12880	3	021-12880	3	021-13191	5
6	Nut, 1/4-28 UNF-3B	021-12109	3	021-11675	3	021-11675	3	021-11675	5
7	Spacer .083 Thk.	064-27519-001	1	-----	—	064-16817-001	1	-----	—
8	Spacer .086 Thk.	064-27519-002	1	-----	—	064-16817-002	1	-----	—
9	Spacer .089 Thk.	064-27519-003	1	-----	—	064-16817-003	1	-----	—
10	Spacer .092 Thk.	064-27519-004	1	-----	—	064-16817-004	1	-----	—
11	Spacer .098 Thk.	064-27519-005	1	-----	—	064-16817-005	1	-----	—
12	Spacer .110 Thk.	064-27519-006	1	-----	—	064-16817-006	1	-----	—
13	Nut, 12 pt.	064-27520	1	064-16738-001	1	064-18164	1	064-18164	1
7	Spacer .105 Thk.	-----	—	064-16765-001	1	-----	—	064-16765-001	1
8	Spacer .110 Thk.	-----	—	064-16765-002	1	-----	—	064-16765-002	1
9	Spacer .115 Thk.	-----	—	064-16765-003	1	-----	—	064-16765-003	1
10	Spacer .120 Thk.	-----	—	064-16765-004	1	-----	—	064-16765-004	1
11	Spacer .130 Thk.	-----	—	064-16765-005	1	-----	—	064-16765-005	1
12	Spacer .150 Thk.	-----	—	064-16765-006	1	-----	—	065-16765-006	1