

OPEN COMPRESSOR PARTS LIST (CONTINUED)

Item No.	Description	Model LTD 53 – 59		Model LTD 67 – 76		Model LTD 85 – 95		Model LTD 108 – 120 – 126	
		YORK Part No.	Quan.	YORK Part No.	Quan.	YORK Part No.	Quan.	YORK Part No.	Quan.
39	Retaining Ring, Internal	—	—	—	—	029-08736	1	—	—
40	Gasket, 30-1/2 O.D. x 27-1/2 I.D. x 1/16 Thk.	—	—	064-27980	1	● 064-15521	1	—	—
41	Suction, Connection Low Speed Pump	—	—	—	—	064-21476	1	—	—
42	Suction Tube – Low Speed Oil Pump	—	—	—	—	064-15519	1	—	—
43	“O” Ring 1” O.D. x 3/4 I.D. x 1/8 Thk.	—	—	—	—	● 028-03282	2	—	—
44	Inner Seal Plate Gasket	† 070-12260	1	■ 064-11806	1	● 064-12144	1	★ 064-23013	1
45	Seal Plate	064-12259	1	064-11656	1	064-12252	1	064-22964	1
46	Oil Separator Gasket	† 070-15440	1	■ 064-11803	1	● 064-12145	1	★ 064-23014	1
47	Insert Pin	See Item 29	—	029-06855	1	028-06875	1	029-06855	1
48	Rotor Support to Oil Separator Gasket	—	—	—	—	—	—	★ 064-23012	1
49	Oil Separator Plate	064-21066	1	064-20436	1	064-21431	1	See Table 4	1
50	Ring Seal (Impeller)	† 064-21073	1	■ 064-20435	1	● 064-21430	1	See Table 4	1
51	Flat Spring Washer	064-12887	1	064-12887	1	064-21429	1	See Table 4	1
52	Retaining Ring Internal	029-05601	1	029-05601	1	029-08600	1	See Table 4	1
53	Main Shaft (High Speed)	064-12512	1	064-11655	1	See Table 3	1	064-22729	1
54	Impeller	See Table 1	1	See Table 2	1	See Table 3	1	See Table 4	1
55	Impeller Clamping Collar	064-09228	1	064-11659	1	064-21477	1	064-23093	1
56	Special Washer	064-16500	1	064-16500	1	064-21478	1	—	—
57	Cap Screw, 12 Pt. Hd. – 5/8 – 18 UNF x 2-3/4 Lg.	021-12347	1	—	—	—	—	—	—
	Cap Screw, 12 Pt. Hd. – 5/8 – 18 UNF x 3-3/4 Lg.	—	—	021-12151	1	—	—	—	—
	Cap Screw, 12 Pt. Hd. – 3/4 – 16 UNF x 4-3/4 Lg.	—	—	—	—	021-12174	1	—	—
	Cap Screw, 12 Pt. Hd. – 1/2 – 20 UNF-3A x 6 Lg.	—	—	—	—	—	—	021-11998	4
58	Base Plate Nozzle Gasket	† 064-20802	1	■ 064-20660	1	064-21463	1	See Table 4	1
59	PRV Gasket to Scroll	—	—	—	—	—	—	★ 064-23008	1
60	Rotor Support Gasket to Scroll	—	—	—	—	—	—	★ 064-23015	1
61	Plug Sight 1-1/2”	026-16556	2	026-16556	2	026-16556	2	026-16556	2
62	“O” Ring 3” O.D. x 1/16 Sect.	028-09561	1	028-09562	1	028-09562	1	028-09577	1
63	Tube 3/4 O.D. x .049 Wall	064-27288	1	064-27288	1	064-31782	5	—	—
64	—	—	—	—	—	—	—	—	—
65	Dowel Pin 1/2” Dia. x 2” Lg.	029-10646	3	029-10646	3	029-10646	3	029-10646	3
66	Tube 3/4 O.D. x .049 Wall	—	1	—	—	—	—	064-31781	2
70	“O” Ring – 4-1/4” O.D. x 4 I.D. x 1/8 Sect.	—	—	—	—	028-04349	1	—	—
71	Tubing 1/4” O.D. x .035 Wall	064-31759	1	—	—	—	—	—	—
72	Ell, 45°, 3/4 Tube x 3/4 MPT	023-07264	2	023-07264	2	023-07264	2	023-07264	4
73	Oil Eliminator (Frame Type)	364-13699	1	364-13441	1	364-18474	1	364-23041	1
74	Oil Eliminator (Can Type)	364-13347	1	364-13347	2	364-13347	2	—	—
75	Coupling, 1/2 Tube x 1/2 FPT	023-07559	1	—	—	—	—	—	—
	Coupling, 5/8 Tube x 1/2 FPT	—	—	023-07342	2	—	—	—	—
	Coupling, 3/4 Tube x 1/2 FPT	—	—	—	—	023-07661	2	—	—

† Parts included in Field Replacement Kit – Models LTD53 & LTD59 – Part No. 464-29624

■ Parts included in Field Replacement Kit – Models LTD67 & LTD76 – Part No. 464-29626

● Parts included in Field Replacement Kit – Models LTD85 & LTD95 – Part No. 464-29628

★ Parts included in Field Replacement Kit – Models LTD108, LTD120 and LTD126 - Part No. 464-29630