

## REFRIGERANT TRANSFER UNIT




FIG. 19— REFRIGERANT TRANSFER UNIT — FRONT VIEW (SEE PARTS LIST PAGE 20)

Voltage	Part No.
208-3-60	366-13641-002
220/440-3-60	366-13641-003
230/460-3-60	366-13641-003
240/480-3-60	366-13641-003
550/575/600-3-60	366-13641-005
380-3-50	366-13641-006
415-3-50	366-13641-008