



AUXILIARY CONTROL BOX



NOTE: Unit less transfer unit do not contain items 2, 8 and only quan. 1 of item 1 (12M).

NOTE: Units less transfer unit do not contain item 3, 7 & 8.

Item	Description	OT TURBOPAK W/Transfer Unit 366-80747-001		OT TURBOPAK W/O Transfer Unit 366-80748-001	
		Quan.	Part No.	Quan.	Part No.
1	Contactor (12M)* (13M)**	2	024-19325	1	024-19325*
2	Switch (Transfer Unit)	1	024-11736	—	—
3	Terminal Block (3PH - 50/60)	1	025-07725	1	025-07725
4	Terminal Block (1PH - 50/60)	36	025-20945	36	025-20945
5	Terminal Block End	2	025-20946	2	025-20946
6	Strip Marker (1PH - 50/60)	1	025-20514	1	025-20514
7	Strip Marker	1	025-20515	—	—
8	Nameplate, Transfer Unit Switch	1	029-11140	—	—
9	Pawl Fastner	1	021-13025	1	021-13025

*(12M) — Oil Pump Contactor
 **(13M) — Transfer Unit Contactor

NOTE: HT and OT units without transfer unit do not include items 3, 10, and only quan. 1 of item 2.

FIG. 4 — AUXILIARY CONTROL BOX