



ITEM NO.	DESCRIPTION	PART NO.	
		STYLE E	STYLE F
1	Screw - 7/16 - 14 x 2 (14 Req'd.)	021-13198	021-13198
2	Lockwasher - 7/16 (10/Pk'g.)	221-01161-800	221-01161-800
3	Washer, Plain - 7/16 (10/Pk'g.)	221-14111-800	221-17270-800
4	Bolt, Terminal (6 Req'd.)	021-12696	021-12696
5	Gasket, Terminal Bolt (6 Req'd.)	064-36151	064-36151
6	Washer, Terminal Bolt (10/Pk'g.)	228-09410-800	228-09410-800
7	Nut, Hex (6/Pk'g.)	221-12724-800	221-12724-800
8	Screw, Overload Protector (5/Pk'g.)	221-14817-800	221-14817-800
9	Terminal, Overload (Style E - 4 Req'd. Style F - 8 Req'd.)	025-18650	025-18650
10	Washer, Plain (10/Pk'g.)	221-01240-800	221-01240-800
11	Seal, O-Ring (Style E - 2 Req'd. Style F - 4 Req'd.)	028-09347	028-09347
12	Washer, Terminal (10/Pk'g.)	228-09525-800	228-09525-800
13	Lockwasher (20/Pk'g.)	221-01133-800	221-01133-800
14	Nut, Hex (10/Pk'g.)	221-09991-800	221-09991-800
15	Block, Terminal	025-27801	025-19978
16	Gasket, Terminal Block	064-21839	064-21839
17	Spacer, Insulating (2 Req'd.)	064-47346	064-47346
18	Block, Term. Base, Flat (Style E - 13 Req'd. & Style F - 15 Req'd.)	025-20944	025-20944
19	Block, Term. End	025-20946	025-20946
20	Bar, Jumper*	064-47424	064-47424
21	Module, Motor Protector, 120V	-	025-27522
	Module, Motor Protector, 240V	-	025-28722
	Module, Motor Protector, 24V	-	025-29939
22	Box, Terminal	364-47342	364-47606
23	Cover, Terminal Box	064-46993	064-47459
24	Screw, Term. Box Cover	021-08197	021-13784
25	Lockwasher	-	021-01133
26	Washer, Plain	021-17646	021-17646

*Used ● across-the-line start



STYLE E

#23362



STYLE F

FIG. 8 - TERMINAL PLATE