



**KEY**

(1) (2)	CYLINDER NUMBERS	●	UNLOADING CYLINDERS	○	PERMANENTLY LOADED CYLINDERS	○ 1 ○ 2 ○ 3	UNLOADER SOLENOID NUMBERS
------------	---------------------	---	------------------------	---	---------------------------------	-------------------	---------------------------------

TYPE UNLOADING	4 CYL. COMPRESSOR		6 CYL. COMPRESSOR		8 CYL. COMPRESSOR	
	QTY. OF UNLOADING CYLINDERS	CYLINDER LOCATION NUMBER	QTY. OF UNLOADING CYLINDERS	CYLINDER LOCATION NUMBER	QTY. OF UNLOADING CYLINDERS	CYLINDER LOCATION NUMBER
1 SOL	2 (OPT.)	3,4	—	—	—	—
2 SOL	—	—	4 (OPT.)	1,2,5,6	4 (OPT.)	1,2,5,6
3 SOL	3 (ST'D.)	1,3,4	4 (ST'D.)	1,2,5,6	6 (ST'D.)	1,2,5,6,7,8

ITEM NO.	DESCRIPTION	PART NO.
Ⓢ 22	Sleeve, Unloader	064-47195
Ⓢ 23	Device, Unloader	364-21681
Ⓢ 23A	Union, Unloader Device	023-05839
23B	Plug, Pipe 3/8 NPTE	023-04298

**FIG. 10 — UNLOADING DEVICE**