

ITEM NO.	DESCRIPTION	QUANTITY	PART NO.
54	Terminal Box	1	664-48175-000
54A	Cover, Terminal Box	1	064-47459-000
54B	Screw, Tap	9	021-13784-000
54C	Lockwasher, Internal Tooth	6	021-01133-000
54D	Screw, Pan Head	2	021-03743-000
54E	Screw, 3/8 Hex Flange	16	021-17691-000
54F	Lockwasher, 3/8 Internal Tooth	4	021-01155-000
54G	Washer, Plain, 7/16 ID x 1 OD	16	021-01267-000
54H	Bolt, Terminal	6	021-12696-000
54I	Gasket, Terminal Bolt, 13/16 OD	6	064-36151-000
54J	Washer, Terminal Bolt (Package of 10)	—	228-09410-800
	No. of Washers Req'd Per Compressor	12	
54K	Washer, Plain	6	021-17646-000
54L	Nut, 7/16 Hex (Package of 6)	—	221-12724-800
	No. of Nuts Req'd Per Compressor	18	
54M	Lockwasher, 7/16 Internal Tooth	6	021-16246-000
54N	Screw, Cap Hex Soc Hd (Package of 5)	—	221-14817-800
	No. of Screws Req'd. Per Compressor	4	
54O	Terminal, Overload	8	025-18650-000
54P	Washer, Plain, 3/16 ID (Package of 5)	—	221-01240-800
	No. of Washers Req'd. Per Compressor	4	
54Q	Seal, O-Ring, 5/32 ID	4	028-09347-000
54R	Washer, Terminal (Package of 10)	—	228-09525-000
	No. of Washers Req'd. Per Compressor	8	
54S	Nut, Hex, Machine Screw	4	021-08661-000
54T	Terminal Block	1	025-30402-000
54U	Gasket, Terminal Block	1	028-12557-000
54V	Spacer, Insulating	2	064-47346-000
54W	Terminal Block, Flat Base	See Table 1	025-20944-000
54X	Terminal Block End	1	025-20946-000
54Y	Bar, Jumper*	1	064-47424-000
54Z	Module, Motor Protector; Control Voltage:	1	
	24V		025-29939-000
	120V Dual Voltage, Auto Reset		025-32539-000
	240V Dual Voltage, Auto Reset		025-32539-000

* (Not Shown) Used in Across-the-Line Applications.

FIG. 10 – TERMINAL BOX (Cont'd.)