

ITEM NO.	DESCRIPTION	COMPRESSOR		
		4 CYLINDER	6 CYLINDER	8 CYLINDER
25A	PUMP, OIL (BARE)	026-35003-000	026-35003-000	026-35003-000
26	GASKET, OIL PUMP	028-12556-000	028-12556-000	028-12556-000
27	SCREW, HEX FLANGE (6 REQUIRED)	021-17689-000	021-17689-000	021-17689-000
§28	CRANKSHAFT			
	STROKE 3	364-49221-000	364-49222-000	364-49223-000
	STROKE 4	364-49224-000	364-49225-000	364-49226-000
29	WASHER, THRUST	029-11098-000	029-11098-000	029-11098-000
§30	MOTOR		SEE TABLE 3	
31	KEY, MOTOR	064-26560-000	064-26560-000	064-26560-000
32	WASHER, SHAFT	064-21835-000	064-21835-000	064-21835-000
33	SCREW, 5/8 HEX CAP	021-01630-000	021-01630-000	021-01630-000
34	LOCKWASHER, SHAFT	021-05295-000	021-05295-000	021-05295-000
§35	SCREEN, OIL STRAINER	029-20032-000	029-20032-000	029-20032-000
36	RETAINING CMPD, LOCTITE (Use With Item 35)	013-01752-000	013-01752-000	013-01752-000
§37	VALVE, RELIEF	022-03871-000	022-03871-000	022-03871-000
	NO. REQUIRED PER COMPRESSOR	1	2	2
§38	UNLOADER PISTON		SEE FIGURE 4	
	NO. REQUIRED PER COMPRESSOR		SEE TABLE 1	
§39	VALVE, SOLENOID	025-29999-000	025-29999-000	025-29999-000
	NO. REQUIRED PER COMPRESSOR		SEE TABLE 1	
§40	COIL, SOLENOID (LESS VALVE)			
	120 VOLT	025-30976-000	025-30976-000	025-30976-000
	240 VOLT	025-30977-000	025-30977-000	025-30977-000
	NO. REQUIRED PER COMPRESSOR		SEE TABLE 1	
§41	GASKET, SOLENOID VALVE	028-12558-000	028-12558-000	028-12558-000
	NO. REQUIRED PER COMPRESSOR	1	2	3
42	SCREW, 3/8 HEX CAP	021-17690-000	021-17690-000	021-17690-000
	NO. REQUIRED PER COMPRESSOR	6	12	18
43	COVER, ACCESS	064-48176-000	064-48176-000	064-48176-000
	NO. REQUIRED PER COMPRESSOR	1	2	3
44	PIN, COILED SPRING	029-21378-000	029-21378-000	029-21378-000
	NO. REQUIRED PER COMPRESSOR	1	2	3
45	SCREW, 7/16 HEX FLANGE	021-17693-000	021-17693-000	021-17693-000
	NO. REQUIRED PER COMPRESSOR	16	32	48
46	COVER, HANDHOLD (2 REQUIRED)	064-21645-000	064-21645-000	064-21645-000
47	VALVE CAGE ASSY (DISCHARGE)		SEE FIGURE 6	
	NO. REQUIRED PER COMPRESSOR	4	6	8
48	SCREW, DISCH. VALVE CAGE	021-16827-000	021-16827-000	021-16827-000
	NO. REQUIRED PER COMPRESSOR	16	24	32
49	PLATE, VALVE SUCTION		SEE FIGURE 7	
	NO. REQUIRED PER COMPRESSOR	4	6	8
50	SLEEVE, CYLINDER	064-48192-000	064-48192-000	064-48192-000
	NO. REQUIRED PER COMPRESSOR	4	6	8
51	SEAL, O-RING, CYLINDER SLEEVE	028-12259-000	028-12259-000	028-12259-000
	NO. REQUIRED PER COMPRESSOR ¹		SEE TABLE 1	
§52	PISTON ASSEMBLY		SEE FIGURE 8	
§53	CONNECTING ROD ASSEMBLY		SEE FIGURE 9	
54	TERMINAL BOX		SEE FIGURE 12	

NOTES: § = Recommended Stock Spare Part
¹ = One (1) Required on Each Unloading Cylinder