


Item No.	Description	Part No.
2	Fuse	025-05749
3	Capacitor, Run (2 Req'd.)	024-20050
4	Contactor (8M, 14M)	024-18496
5	Contactor, 2M, 4M)	024-18912
6	Contactor (5M, 6M, 7M, 11M, 12M, 13M)	024-18023
7	Contactor (1M, 3M)	024-20487
8	Lug, Electrical	025-19282
9	Block, Terminal	025-18807
10	Block, Term. Base Flat (8 Req'd.)	025-20944
11	Block, Terminal, End	025-20946

FIG. 7 — POWER PANEL LCHA65-28C & 28D



Item No.	Description	Part No.	
		-46	-58
1	Fuseholder	025-13947	025-13947
2	Fuse	025-05741	025-11910
3	Capacitor, Run	024-20050	024-20050
4	Contactor (8M, 14M)	024-18496	024-18496
5	Contactor (5M, 6M, 7M, 11M, 12M, 13M)	024-18023	024-18023
6	Contactor (1M, 3M)	024-20487	024-18977
7	Block, Terminal	025-18807	025-18807
8	Lug, Electrical	025-19282	025-19282
9	Block, Term. Base Flat (8 Req'd.)	025-20944	025-20944
10	Block, Terminal, End (2 Req'd.)	025-20946	025-20946

FIG. 8 — POWER PANEL LCHA65-46C, 46D, -58C & 58D