


ITEM NO.	DESCRIPTION	PART NUMBER
1	Cage, Discharge Valve	064-49658-000
2	Plate, Inner Valve	064-48032-000
3	Ring, Discharge Valve	064-43012-000
4	Screw, 3/8 Socket Button Cap	021-17649-000
5	Nut, 3/8 Hex Self Locking	021-09932-000
6	Spring, Wave (2 Required)	022-10021-000
^s 23 (Table 2)	Cage, Discharge Valve, Assembly Includes Items 1 through 6	664-49722-000

^s = Recommended Stock Spare Part

FIG. 50 – DISCHARGE VALVE CAGE ASSEMBLY (SEE TABLES 6 & 7)



ITEM NO.	DESCRIPTION	PART NUMBER
1	Plate, Valve	064-49657-000
2	Spring, Wave (2 Required)	022-09742-800
3	Ring, Suction Valve	022-10020-000
^s 22 (Table 2)	Plate, Suction Valve, Assembly Includes Items 1 through 3	664-49723-000

^s = Recommended Stock Spare Part

FIG. 51 – SUCTION VALVE PLATE ASSEMBLY (SEE TABLES 6 & 7)