

REPLACEMENT COMPRESSORS\*, \*\*

CURRENT CODE	CURRENT	SS42C	SS62C	SS63C
-17	200-3-60	365-24976-002	365-24977-002	365-24978-002
-28	230-3-60	365-24976-003	365-24977-003	365-24978-003
-46	460-3-60	365-24976-004	365-24977-004	365-24978-004
-58	575-3-60	365-24976-005	365-24977-005	365-24978-005
-63	220-3-50	365-24976-006	365-24977-006	365-24978-006
-64	346-3-50	365-24976-007	365-24977-007	365-24978-007

\*Replacement Compressor Part Numbers shown above include initial oil charge but do not include crankcase oil heater, motor protector module, or suction and discharge stop valves. (Order separately from following chart.)

CRANKCASE OIL HEATER	025-19347-001	120 VOLTS
	025-19347-002	240 VOLTS
MOTOR PROTECTOR MODULE	025-20791-001	120 VOLTS
	025-20791-002	240 VOLTS

STOP VALVES	SS42C	SS62C	SS63C
SUCTION	022-03727-003	022-01393	022-01394
DISCHARGE	022-03422	022-03727-003	022-03727-003

\*\*Replacement Compressor Part Numbers shown above include "P.E." Unloader Solenoid Valve(s) but do not include Solenoid Coil(s). Production Compressors were built with either "P.E." or Sporlan Solenoid Valves. Solenoid Valves are interchangeable but Solenoid Coils are not interchangeable. (Order correct Coil and/or Valve from following chart.)

VALVE MANUFACTURER	VALVE PART NO. (LESS COIL)	SOLENOID COIL PART NO.	
		120 VOLT	230 VOLT
P.E.	025-25145	025-16572-003	025-16572-001
SPORLAN	025-25147	025-25146	025-25146

