



FIG. 1— COMPRESSOR CUT-A-WAY

Item	Description	Part No.				
		4 Cylinder	6 Cylinder	8 Cylinder	12 Cylinder	16 Cylinder
1	Housing, Compressor	064-28846	064-28847	064-28848	064-28849	064-28850
2	Head, Compressor Top	064-28857	064-28857	064-28857	064-28857	064-28857
3	Head, Compressor Top No. Req'd.	2	2	2	4	4
4	Gasket, Top Head (1 Per Top Head)	064-28927	064-28858	064-28858	064-28858	064-28858
5	Screw, Top Head** 1/2 x 5 Lg. (4 Per Head)	021-08898	1	2	2	4
6	Screw, Top Head** 3/8 x 7/8 Lg. (2 Per Head)	021-01470				
7	Screw, Top Head** 1/2 x 4-1/2 Lg. (12 Per Head)	021-12308				
8	Screw, Top Head*** 1/2 x 4 Lg. (16 Per Head)	021-12330				
9	Water Jacket, Top Head (1 Per Head)	064-29089				
10	Gasket, Water Jacket (1 Per Jacket)	064-32798				
11	Cover, Handhole	See Fig. 7				
12	Gasket, Handhole (1 Per Cover)	070-02497				
13	Screw, H.H. Cover (16 Per Cover)	021-09592				
14	Connector, Half Union 1/2 FLA x 7/8 NPTE No. Req'd.	023-00923 2	023-00923 4	023-00923 2	023-00923 8	023-00923 4
15	Cap Sealing Caplug — 9 No. Req'd.	029-07837 2	028-07837 2	028-07837 2	028-07837 4	028-07837 4
16	Connection, Water Cooling No. Req'd.	364-31607 1	364-31598 1	364-31592 1	364-31598 2	364-31592 2
17	Connection, Water Cooling No. Req'd.	—	364-31599 1	364-31593 2	364-31599 2	364-31593 4
18	Manifold, Discharge No. Req'd.	364-32806 1	364-32807 1	364-32808 1	364-32807 2	364-32808 2
19	Gasket, Manifold & Spacer No. Req'd.	070-09705 3	070-09705 4	070-09705 6	070-09705 8	070-09705 12
△ 20	Spacer, Manifold No. Req'd.	064-28880 1	064-28880 1	064-28880 2	064-28880 2	064-28880 4
21	Screw, Manifold (1/2 x 5 Lg.) No. Req'd.	021-08898 4	021-08898 8	021-08898 8	021-08898 16	021-08898 16
22	Screw, Manifold (1/2 x 3-3/4 Lg.) No. Req'd.	021-12307 4	021-12307 4	021-12307 8	021-12307 8	021-12307 16

*Not Shown.

**Used on Water Cooled Heads Only.

***Used on Regular Heads Only.