

No.	Sym.	Part Description	Part Number	Unit Size
PURGE SYSTEM (Cont.)				
116	1SOL	Belt Guard Gasket	028-09318	ES 4C1—ES 14F3
117		Absolute Pressure Gage	026-09261	ES 1A1—ES 14F3
118		Ball Valve (1/2" N.P.T.I.)	022-02558	ES 1A1—ES 14F3
119		Solenoid Valve (Purge Suction)	025-11509	ES 1A1—ES 14F3
120		Replacement Solenoid Coil (For 1SOL)	025-11611	ES 1A1—ES 14F3
121		Spare Parts Kit (For 1SOL)	025-14536	ES 1A1—ES 14F3
CONTROLS AND PANEL COMPONENTS				
122		Elem. Wiring Diagram (ESA, ESB — 60 Hz)	035-02167	ES 1A1—ES 14F3
123		Elem. Wiring Diagram (ESA, ESB — 50 Hz)	035-02167	ES 1A1—ES 9E2
124		Elem. Wiring Diagram (ESA, ESB — 50 Hz)	035-02168	ES 10E3—ES 14F3
125		Elem. Wiring Diagram (ESC-ESH — 60 Hz)	035-02166	ES 1A1—ES 14F3
126		Elem. Wiring Diagram (ESC-ESH — 50 Hz)	035-02166	ES 1A1—ES 9E2
127		Elem. Wiring Diagram (ESC-ESH — 50 Hz)	035-02165	ES 10E3—ES 14F3
128		Conn. Wiring Diagram (ESA — 60 Hz)	035-02174	ES 1A1—ES 14F3
129		Conn. Wiring Diagram (ESA — 50 Hz)	035-02174	ES 1A1—ES 9E2
130		Conn. Wiring Diagram (ESA — 50 Hz)	035-02176	ES 10E3—ES 14F3
131		Conn. Wiring Diagram (ESB — 60 Hz)	035-02173	ES 1A1—ES 14F3
132		Conn. Wiring Diagram (ESB — 50 Hz)	035-02173	ES 1A1—ES 9E2
133		Conn. Wiring Diagram (ESB — 50 Hz)	035-02175	ES 10E3—ES 14F3
145		Conn. Wiring Diagram (ESC, ESE, ESG — 60 Hz)	035-02172	ES 1A1—ES 14F3
135		Conn. Wiring Diagram (ESC, ESE, ESG — 50 Hz)	035-02172	ES 1A1—ES 9E2
136		Conn. Wiring Diagram (ESC, ESE, ESG — 50 Hz)	035-02170	ES 10E3—ES 14F3
137		Conn. Wiring Diagram (ESD, ESF, ESH — 60 Hz)	035-02171	ES 1A1—ES 14F3
138		Conn. Wiring Diagram (ESD, ESF, ESH — 50 Hz)	035-02171	ES 1A1—ES 9E2
139		Conn. Wiring Diagram (ESD, ESF, ESH — 50 Hz)	035-02169	ES 10E3—ES 14F3
140	CWC	Controller (Pneu.), Chilled Water	022-02793	ES 1A1—ES 14F3
141	CWS	Chilled Water Temperature Sensor	022-04849	ES 1A1—ES 14F3
142		Instruction Drawing (For CWC)	066-12404	ES 1A1—ES 14F3
143		Key (CWC Adjustment)	025-13356	ES 1A1—ES 14F3
144		Separable Well (For CWS)	026-14175	ES 1A1—ES 14F3
145	HLC(RHW)	Controller, Hi Limit (Recirculated Hot Water)	026-18748	ES 1A1—ES 14F3
146	2PRV,3PRV	Pressure Reducing Valve (Pneu.)	022-01897	ES 1A1—ES 14F3
147	1PE,2PE	Pressure Control Switch (Pneu.—Elect.)	025-09961	ES 1A1—ES 14F3
148	2G—7G	Gage, Pressure	026-10301	ES 1A1—ES 14F3
149	2SOL	Air Solenoid Valve (3-Way)	225-11931-006	ES 1A1—ES 14F3
150	6SOL	Air Solenoid Valve (3-Way)	025-18083	ES 1A1—ES 14F3
151		Replacement Solenoid Coil (For 6SOL)	025-18580	ES 1A1—ES 14F3
152	1RES	Air Restrictor	026-13858	ES 1A1—ES 14F3
153		Pneumatic Tubing — Plastic (1/4 O.D. x 120" Lg.)	067-76683	ES 1A1—ES 14F3
154	1TH	Low Temperature Refrig. Thermostat	025-18086	ES 1A1—ES 14F3
155	TS	Temperature Sensor	025-17896-001	ES 1A1
156	TS	Temperature Sensor	025-17896-002	ES 1A2—ES 14F3
157		Electronic Test Device (For 1TH, TS)	025-18391	ES 1A1—ES 14F3
158	6TH	ADC Control Thermostat	025-17892	ES 1A1—ES 14F3
159	8TH	Tower Thermostat Water	025-14464	ES 1A1—ES 14F3
160	1TR	Dilution Timer (Steam Units)	325-16341-001	ES 1A1—ES 14F3
161	1TR	Dilution Timer (Hot Water Units)	325-16341-004	ES 1A1—ES 14F3
162	2TR	ADC Control Timer	325-16341-005	ES 1A1—ES 14F3
163	1R	Relay, 3 Pole	024-17027	ES 1A1—ES 14F3
164	2R	Relay, 2 Pole	024-17075	ES 1A1—ES 14F3
165	3R	Relay, Time Delay	024-14967	ES 1A1—ES 14F3
166	4R	Relay, 1 Pole	024-16395-014	ES 1A1—ES 14F3
167	1TB	Terminal Block, 3 Pole	025-07725	ES 1A1—ES 14F3
168	2TB	Terminal Block, (34 Req'd.)	025-15865	ES 1A1—ES 14F3
169	2TB	Terminal End Block	025-13981	ES 1A1—ES 14F3
170	1S	Service Switch, Toggle	024-11735	ES 1A1—ES 14F3