

**TABLE 3— HOT WATER CONTROL VALVES**

Valve Size (In.)	Pneumatic—Cast Iron		Pneumatic—Cast Iron		Pneumatic—Cast Steel	
	Fisher Valves		Honeywell Valves		Fisher	Honeywell
	125 #	250 #	125 #	250 #	300 #	300 #
1	—	—	022-03009	022-03018	—	—
1-1/4	—	—	022-03010	022-03019	—	—
1-1/2	022-04396	022-04397	022-03011	022-03020	022-04398	—
2	022-04399	022-04400	022-03012	022-03021	022-04401	—
2-1/2	022-04402	022-04403	022-03013	022-03022	022-04404	—
3	022-04405	022-04406	022-03014	022-03023	022-04407	—
4	022-04408	022-04409	022-03015	022-03024	022-04410	—
6	022-04411	022-04412	022-03016	022-03025	022-04413	—
8	—	—	022-03017	022-03026	—	—

**TABLE 4— STEAM CONTROL VALVE ASSEMBLIES, ACTUATORS, AND INSTALLATION DRAWINGS**

Valve Size (In.)	Valve Type	Valve Ass'y YORK Part No.	Actuator YORK Part No.	Valve Ass'y Installation Drawings	
				ESA, ESC Units	ESB, ESD Units
3	Cage	022-02624	022-02821	366-52157	366-52158
4	Cage	022-02563	022-02821	366-52157	366-52158
5	Cage	022-02718	022-02821	366-52157	366-52158
6	Cage	022-02625	022-02821	366-52157	366-52158
4	Butterfly	022-03858	—	366-52161	366-52162
5	Butterfly	022-03859	—	366-52161	366-52162
6	Butterfly	022-03860	—	366-52161	366-52162
8	Butterfly	022-04058	—	366-52161	366-52162

**TABLE 5— REFRIGERANT PUMP ISOLATION KIT**

Unit Size	ESA, ESB, ESC, ESD, ESE, ESF, ESG, ESH	
	50 Hertz	60 Hertz
1A1	366-53819	366-53819
1A2	366-53819	366-53819
2A3	366-53819	366-53819
2A4	366-53819	366-53819
2B1	366-53819	366-53819
3B2	366-53819	366-53819
3B3	366-53819	366-53819
4B4	366-53819	366-53819
4C1	366-53819	366-53819
5C2	366-53819	366-53819
5C3	366-53819	366-53819
6C4	366-53819	366-53819
7D1	366-53819	366-53819
7D2	366-53819	366-53819
8D3	366-53819	366-53819
8E1	366-53820	366-53819
9E2	366-53820	366-53819
10E3	366-53820	366-53820
12F1	366-53820	366-53820
13F2	366-53820	366-53820
14F3	366-53820	366-53820

**TABLE 6— SOLUTION PUMP ISOLATION KIT**

Unit Size	ESA, ESC, ESE & ESG		ESB, ESD, ESF & ESH	
	50 Hertz	60 Hertz	50 Hertz	60 Hertz
1A1	366-53809	366-53809	366-53809	366-53809
1A2	366-53809	366-53809	366-53809	366-53809
2A3	366-53809	366-53809	366-53809	366-53809
2A4	366-53809	366-53809	366-53809	366-53809
2B1	366-53810	366-53810	366-53810	366-53810
3B2	366-53810	366-53810	366-53810	366-53810
3B3	366-53810	366-53810	366-53810	366-53810
4B4	366-53810	366-53810	366-53810	366-53810
4C1	366-53810	366-53810	366-53810	366-53810
5C2	366-53810	366-53810	366-53810	366-53810
5C3	366-53810	366-53810	366-53814	366-53814
6C4	366-53814	366-53810	366-53814	366-53814
7D1	366-53814	366-53810	366-53814	366-53814
7D2	366-53814	366-53814	366-53814	366-53814
8D3	366-53814	366-53814	366-53814	366-53814
8E1	366-53815	366-53817	366-53815	366-53817
9E2	366-53815	366-53817	366-53815	366-53817
10E3	—	366-53817	—	366-53817
12F1	—	366-53818	—	366-53818
13F2	—	366-53818	—	366-53818
14F3	—	366-53818	—	366-53818

**TABLE 7— GENERATOR ISOLATION KIT**

Unit	Hertz	Part No.
10E3	50	366-53812
12F1	50	366-53816
13F2	50	366-53816
14F3	50	366-53816

**TABLE 8— ABSORBER ISOLATION KIT**

Unit	Hertz	Part No.
10E3	50	366-53811
12F1	50	366-53813
13F2	50	366-53813
14F3	50	366-53813