



TABLE 2

Item No.	Description	Part No.
1	Cylinder Sleeve Assembly (Includes Items 2,4,5,6,7,8,9,10,11,12,13, 16 & 17)	365-19207
2	Sleeve, Cylinder	065-19206
3	Gasket, Cyl. Sleeve - .010" Thick	070-07378
4	Gasket, Suction Valve (Spacer - .010")	070-07378
5	Valve, Suction	065-00836
6	Spring, Suction Valve (6 Req'd. Per Cyl.)	029-04641
7	Plate, Discharge Valve	065-02444
8	Screw, Discharge Valve	021-01068
9	Gasket, Beveled	028-00574
10	Plate, Inner Discharge Valve	065-03031
11	Valve, Discharge	065-20889
12	Spring, Discharge Valve (6 Req'd. Per Cyl.)	029-04349
13	Cage, Discharge Valve	065-20799
14	Screw, Cap 3/8" x 2" (4 Req'd. Per Cyl.)	021-01510
15	Lockwasher, Spring 3/8"	021-05291
16	Nut, Self Locking	021-09610
17	Ring, Packing "0" Cylinder Sleeve	028-07198

FIG. 2- EXPLODED VIEW CYLINDER SLEEVE AND VALVE ASSEMBLY