

Solid State Starters					
Board	Board p/n	Position	Circuits	Plug housing p/n	Pin p/n
Logic/trigger	031-02001-XXX	J1	12	025-28384-000	025-28386-000
Logic/trigger	031-02001-XXX	J2 thru J4	2	-	025-19674-000
Logic/trigger	031-02001-XXX	J5 and J12	2	025-19672-000	025-20533-000
Logic/trigger	031-02001-XXX	J6 thru J11	2	025-21136-000	025-19674-000
Logic/trigger	031-00925-XXX	J1	12	-----	-----
Logic/trigger	031-00925-XXX	J2 thru J4	2	-----	-----
Logic/trigger	031-00925-XXX	J5 and J13	2	-----	-----
Logic/trigger	031-00925-XXX	J6 thru J11	2	-----	-----
Logic/trigger	031-00925-XXX	J12	4	-----	-----