

TABLE 16 - TEMPERATURE SENSORS AND TRANSDUCERS

ITEM	QTY	DESCRIPTION	MODELS	PART NUMBER
1 ^S	1	Sensor, Outside Air Temperature - Not Shown (Cable Included)	QCC2015C-030C	025-40273-008*
			QCC2040C-045C	025-40273-006*
			QCC2050C-070C	025-40273-003*
8 ^S	2	Transducer, Suction Pressure (0-400psi)	All	025-41756-002
30 ^S	2	Transducer, Discharge Pressure (0-650psi)	All	025-41756-003
40 ^S	2	Switch, High Pressure Cut-Out (Not Shown)	All	025-41535-000

^S Recommended Spare Part

* **NOTE:** Sensor only = 025-29964-000.

See Figure 15 on page 33.




FIGURE 16 - SENSOR HOUSING AND PIN SOCKET PART NUMBERS