



LD05256

FIGURE 23 - REMOTE TEMPERATURE RESET KIT COMPONENTS

TABLE 28 - REMOTE TEMPERATURE RESET KIT COMPONENTS

375-90914-000			
ITEM	QUANTITY	DESCRIPTION	PART NUMBER
1	1	Control, Remote Current/Temperature	031-00814-000
2	1	Bracket, Remote Current/ Temperature Reset	371-01232-361
3	1	Track, Snap	071-01232-363
4	1	Wiring, Remote Current/ Temperature Reset	571-02492-231*
5	2	Screw, Machine Pan Head #4	021-17594-000
6	2	Nut, Hex #4 - 40 Unc-2B	021-10065-000
7	2	Lockwasher, Helical Spring #4 Regular	021-17576-000

*Refer to Table 29

TABLE 29 - REMOTE RESET WIRING

ITEM	QUANTITY	DESCRIPTION	PART NUMBER
8	2	Cont Soc Awg Wire Size 20	025-19674-000
9	2	Terminal Push On Straight	025-06642-000
10	4	Tubing Heat Shrinkable 1/8" I.d.	025-29632-000
11	1	Hgs Connector Electrical Plug	025-32564-000*
12	1	Connector Edge, 15 Position, 0.125	025-17594-000