


TRANSDUCER AND THERMISTOR WIRE HARNESS CONNECTORS - FIELD REPLACEMENT PART NUMBERS



02492-2c

FIGURE 18 - TRANSDUCER AND THERMISTOR WIRE HARNESS CONNECTORS - FIELD REPLACEMENT PART NUMBERS

TABLE 22 - TRANSDUCER AND THERMISTOR WIRE HARNESS CONNECTORS - FIELD REPLACEMENT PART NUMBERS

ITEM	LOCATION	DESCRIPTION	PINS	PART NUMBER
1	TRANSDUCER	(0-400 psis)	3 Pin End	025-41756-002
		(0-650 psis)		025-41756-003
2	WIRE HARNESS	Plug Connector	3 Pin End	025-41761-000
3		Contact Pins		025-41812-000
4	TEMPERATURE SENSOR	Plug Connector	2 Pin End	025-28948-000
5		Contact Pins		025-28949-000
6		Rubber Collar		025-28950-000
7	WIRE HARNESS	Plug Connector	2 Pin End	025-28951-000
8		Contact Pins		025-28952-000
9		Rubber Collar		025-28950-000