



TRANSDUCER AND THERMISTOR WIRE HARNESS CONNECTORS

FIELD REPLACEMENT PART NUMBERS



Item No.	Location	Description	Pins	Part Number
1	Transducer	(0-200 PSIS)	3 Pin End	025-41756-001
		(0-400 PSIS)		025-41756-002
		(0-650 PSIS)		025-41756-003
		(0-150 PSIS)		025-41756-004
		(0-175 PSIS)		025-41756-005
2	Wire Harness	Plug Connector	3 Pin End	025-41761-000
3		Contact Pins		025-41812-000



ITEM NO.	LOCATION	DESCRIPTION	PINS	PART NUMBER
4	Temperature Sensor	Plug Connector	2 Pin End	025-28948-000
5		Contact Pins		025-28949-000
6		Rubber Collar		025-28950-000
7	Wire Harness	Plug Connector	2 Pin End	025-28951-000
8		Contact Pins		025-28952-000
9		Rubber Collar		025-28950-000

FIGURE 18 - TRANSDUCER AND THERMISTOR WIRE HARNESS CONNECTORS - FIELD REPLACEMENT PART NUMBERS