

TABLE 56 - CONTROL PANEL AND POWER PANEL IDENTIFIERS FOR HIGH AIR FLOW FANS (CONT'D)

MODEL	VOLTAGE (PIN 11 & 12)	SINGLE POINT TERMINAL BLOCK (SX)	SINGLE POINT NON-FUSED DISCONNECT SWITCH (SD)	SINGLE POINT CIRCUIT BREAKER (BX)	SINGLE POINT CIRCUIT BREAKER W/ LOCKABLE HANDLE, 65KA SCWR (BC)
QTC3085T, QTC3090T	17	N/A	N/A	N/A	N/A
	28	N/A	N/A	N/A	N/A
	40	371-05244-190	371-05246-290	371-05246-390	371-05246-668
	46	371-05244-191	371-05246-291	371-05246-391	371-05246-669
	58	N/A	N/A	N/A	N/A
QTC3095T AND QTC3100T	17	N/A	N/A	N/A	N/A
	28	N/A	N/A	N/A	N/A
	40	371-05246-162	371-05246-262	371-05246-362	371-05246-662
	46	371-05246-163	371-05246-263	371-05246-363	371-05246-663
	58	N/A	N/A	N/A	N/A
QTC3110T AND QTC3120T	17	N/A	N/A	N/A	N/A
	28	N/A	N/A	N/A	N/A
	40	371-05244-164	371-05244-264	371-05244-364	371-05244-664
	46	371-05244-165	371-05244-265	371-05244-369	371-05244-665
	58	N/A	N/A	N/A	N/A
QTC3125T, QTC3130T	17	N/A	N/A	N/A	N/A
	28	N/A	N/A	N/A	N/A
	40	371-06570-106	371-06570-206	371-06570-306	371-06570-606
	46	371-06570-107	371-06570-207	371-06570-307	371-06570-607
	58	N/A	N/A	N/A	N/A
QTC3140T, QTC3150T	17	N/A	N/A	N/A	N/A
	28	N/A	N/A	N/A	N/A
	40	371-05246-170	371-05246-270	371-05246-374	371-05246-670
	46	371-05246-171	371-05246-274	371-05246-375	371-05246-671
	58	N/A	N/A	N/A	N/A
QTC3160T, QTC3170T	17	N/A	N/A	N/A	N/A
	28	N/A	N/A	N/A	N/A
	40	371-05247-160	371-05247-260	371-05247-360	371-05247-660
	46	371-05247-161	371-05247-261	371-05247-361	371-05247-661
	58	N/A	N/A	N/A	N/A

To identify replacement part numbers, select panel identifier number from *Table xx* or from the panel identifier label shown on *Figure xx*, then refer to the power panel component. See *Table xx* through *Table xx* and *Figure xx* through *Figure xx*.