

**TABLE 73 - HEAT RECOVERY ASSEMBLY (CONT'D)**

ITEM	DESCRIPTION	MODEL	PART NUMBER	SAP NUMBER	FIGURE
10	Liquid Line 1-1/8" HR	QTC3070T, QTC3075T, QTC3085T	092-07688-160	845020	40, 41
	Line Discharge HR System 1	QTC3090T - QTC3110T	092-07688-775	1084548	
	Line Discharge HR System 2	QTC3120T, QTC3125T, QTC3140T	092-07688-615	1034675	
		QTC3130T	092-07688-645	1034677	
		QTC3150T	092-07688-593	993316	
	QTC3160T, QTC3170T	092-07688-596	993319		
11	Liquid Line 1-1/8" HR	QTC3070T, QTC3075T, QTC3085T	092-07688-163	845291	40, 41
	Line Discharge HR System 1	QTC3090T - QTC3110T	092-07688-776	1084549	
12	Liquid Line 1-1/8" HR	QTC3070T, QTC3075T, QTC3085T	092-07688-159	845019	40, 41
	Line Discharge HR System 1	QTC3090T - QTC3100T	092-07688-778	1084711	
		QTC3110T	092-07688-781	1084714	
13	Liquid Line 1-1/8" HR	QTC3070T, QTC3075T, QTC3085T	092-07688-164	845292	40, 41
	Line Discharge HR System 1	QTC3090T - QTC3110T	092-07688-772	1084545	
	Line Liquid HR System 1	QTC3120T	092-07688-609	1034520	
		QTC3125T - QTC3140T	092-07688-605	1034516	
		QTC3150T - QTC3170T	092-07688-591	993314	
100	Heat Exchanger DB400-102	QTC3070T, QTC3075T, QTC3085T	375-84467-100	552463	40, 41
	Heat Exchanger 102 Plate		026-45615-102	409781	
	Heater 120 Volts, 35 Watts		025-42878-000	740166	
	Insulation Heat Exchanger		075-83052-001	401794	
	Insulation Heat Exchanger		075-83052-002	401796	
	Heat Exchanger 102 Plate	QTC3090T - QTC3110T	026-45615-102	409781	
	Heat Exchanger Sub Assy 130 PI	QTC3120T - QTC3130T	375-84467-200	552464	
	Heat Exchanger 130 Plate		026-45615-130	427752	
	Heater 120 Volts, 35 Watts		025-42878-000	740166	
	Insulation Heat Exchanger		075-83052-001	401794	
	Insulation Heat Exchanger		075-83052-002	401796	
	Heat Exchanger Sub Assy 162 PI	QTC3140T - QTC3170T	375-84467-300	552465	
	Heat Exchanger 162 Plate		026-45615-162	629537	
	Heater 120 Volts, 35 Watts		025-42878-000	740166	
	Insulation Heat Exchanger		075-83052-001	401794	
	Insulation Heat Exchanger		075-83052-002	401796	
	101	Bracket Support Heat Exchanger	QTC3070T - QTC3170T	075-76401-000	
103	Bracket Heat Exchanger	QTC3070T, QTC3075T, QTC3085T	092-07700-020	845317	40, 41
		QTC3090T - QTC3170T	092-07700-024	856111	
104	Brace Support Heat Exchanger	QTC3070T - QTC3110T	092-07700-060	1084722	40
		QTC3120T - QTC3170T	092-07700-018	845315	
105	Beam Support Heat Exchanger	QTC3070T, QTC3075T, QTC3085T	092-07700-015	845314	40, 41
		QTC3090T - QTC3170T	092-07700-023	856110	
106	Bracket Pipe Support	QTC3090T - QTC3110T	092-07700-069	1084724	40, 41
		QTC3120T - QTC3170T	092-07700-019	845316	
107	Bracket Pipe Support	QTC3070T - QTC3110T	092-07700-059	1084721	*
122	Bracket Pipe Support	QTC3070T - QTC3110T	075-75051-008	845018	*