

**TABLE 6 - VSD / CONTROL PANEL (PIN 12 & 13 = 50) (CONT'D)**

ITEM	MODELS	PIN 17 =	FANS	DESCRIPTION	PART NUMBER	SAP NUMBER	FIGURE
<b>42</b>	150S, 165H, 175P, 185(S, H, P), 175C, 210(S, H, P), 230S, 240(H, P), 260S, 270(C, S, H, P), 290H, 300(S, H), 310P, 315P, 320S, 330S, 340(S, H),	S, B, N	All	Cable Gate Driver	571-04178-281	427925	2
<b>42a</b>	370(P, S, H)	S, B, N	All	Control, VSD Logic Board	031-02507-003	947328	*
<b>43</b>	150S, 165H, 175P, 185(S, H, P), 175C, 210(S, H, P), 230S, 240(H, P), 260S, 270(C, S, H, P), 290H, 300(S, H), 310P, 315P, 320S, 330S, 340(S, H),	S, B, N	All	Cable Gate Driver	571-04178-282	427926	2
<b>58</b>	150S, 165H, 175P, 185(S, H, P), 175C, 210(S, H, P), 230S, 240(H, P), 260S, 270(C, S, H, P), 290H, 300(S, H), 310P, 315P, 320S, 330S, 340(S, H),	S, B, N	All	SD Card with Software Control Bd	031-03476-010	1201877	4
	370(P, S, H), 400P, 405S, 410(H, P), 450S - 500S	All D, S, M, T, P, O	All	Blank SD Card	031-03476-013 031-03466-000	1201878 1152945	
<b>59</b>	All Models	All	All	EPROM, VSD Logic	031-03422-010	947512	4
<b>61</b>	All Models	All	All	Switch Keypad	024-34930-000	247624	4
<b>62</b>	All Models	All	All	Display LCD	031-02508-000	743925	4
<b>63</b>	All Models	All	All	Switch, Two Position	024-34951-000	736122	4
<b>68</b>	150S, 165H, 175P, 185(S, H, P), 175C, 210(S, H, P), 230S, 240(H, P), 260S, 270(C, S, H, P)	S, B, N	All	Cable Display to Micro	571-04178-261	807007	4,5
	290H, 300(S, H), 310P, 315P, 320S, 330S, 340(S, H)	S, B, N	All		571-04178-268	807013	
	370(P, S, H), 400P, 405S, 410(H, P), 450S - 500S	All	All		571-04178-266	807011	
<b>69</b>	150S, 165H, 175P, 185(S, H, P), 175C, 210(S, H, P), 230S, 240(H, P), 260S, 270(C, S, H, P)	S, B, N	All	Cable Keypad to Micro	571-04178-262	505907	4,5
	290H, 300(S, H), 310P, 315P, 320S, 330S, 340(S, H)	S, B, N	All		571-04178-269	807014	
	370(P, S, H), 400P, 405S, 410(H, P), 450S - 500S	All	All		571-04178-267	807012	
<b>70</b>	All Models	All	All	Cable Ribbon Relay	571-04178-263	807008	4
<b>71</b>	150S, 165H, 175P, 185(S, H, P), 175C, 210(S, H, P), 230S, 240(H, P), 260S, 270(C, S, H, P), 290H, 300(S, H), 310P, 315P, 320S, 330S, 340(S, H),	S, B, N	All	Cable Logic to Control	571-04178-271	807015	5
<b>72</b>	All Models	All	All	Stepper Motor EEV	031-02742-000	744082	1
<b>77</b>	All Models	All	All	Cable Ribbon Relay	571-04178-264	807009	4
<b>88</b>	All Models	All	All	Fuse, Semi Conductor	025-38523-000	739590	1